



# Installation Instructions

## Model Number FDV200S Free Standing Direct Vent Gas Stove



Model Numbers: FDV200SN, FDV200SNE, FDV200SNE2, FDV200SLP, FDV200SLPE, FDV200SLPE2

Certified to: CSA/ANSI Z21.88:19 • CSA 2.33:19 and CSA2.17-2017

This appliance may be installed in an aftermarket, permanently located, manufactured home (USA only) or mobile home, where not prohibited by local codes.  
This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases, unless a certified kit is used.

### **⚠ WARNING:** **FIRE OR EXPLOSION HAZARD**

Failure to follow safety warnings exactly could result in serious injury, death, or property damage.

-Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

### **-WHAT TO DO IF YOU SMELL GAS**

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Leave the building immediately.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department

-Installation and service must be performed by a qualified installer, service agency or the gas supplier.

## **! DANGER**



**HOT GLASS WILL  
CAUSE BURNS.**

**DO NOT TOUCH GLASS  
UNTIL COOLED.**

**NEVER ALLOW CHILDREN  
TO TOUCH GLASS.**

A barrier designed to reduce the risk of burns from the hot viewing glass is provided with this appliance and must be installed for the protection of children and other at-risk individuals.

If the barrier becomes damaged, the barrier must be replaced with the manufacturer's barrier for this appliance.

**INSTALLER: Leave this manual with the appliance.**

**CONSUMER: Retain this manual for future reference.**

**For Propane Horizontal installations the venting must be an additional one foot above the minimum vertical rise off the flue before going horizontal.**

**NOT FOR USE WITH SOLID FUEL.**



A Division of R-Co. Inc.  
2340 Logan Ave.  
Winnipeg, Manitoba Canada  
R2R 2V3 Ph.: (204) 632-1962  
Printed in Canada July 8, 2024  
Part# 200S-MAN19



|   |       |
|---|-------|
| Table of Contents.....  | 2-3   |
| Safety Screen Attachment / Removal.....   | 4     |
| Pre-installation Questions and Answers / Operating Instructions.....                      | 5     |
| Annual Inspection List for Determining Safe Operation of a Direct Vent Gas Fireplace..... | 6     |
| Warnings, Installations, and Operations.....  | 7     |
| Installation Requirements for the Commonwealth of Massachusetts.....                      | 8     |
| Carbon Monoxide (CO) Detector.....  | 8     |
| Mobile Home/Manufactured Housing Installation.....  | 9     |
| Fireplace Dimensions / Locating Your Appliance.....                                       | 10    |
| Clearance to Combustibles.....  | 10    |
| Component Locations.....  | 11    |
| Component Cover.....  | 12    |
| Optional Fan Kit Installation.....  | 13    |
| Split Receptacle- Switch Control Outside of Fireplace.....                                | 14    |
| F200RL Brick Liner Installation.....  | 15    |
| LOGC200 Log Installation.....   | 16    |
| Door and Glass Information.....   | 17    |
| Gas Line Installation.....  | 18    |
| Burner System Maintenance.....  | 19    |
| Conversion Kit Instructions – PART A.....   | 19-20 |
| Gas Conversion for Top Convertible Pilot – Part B (series 0190XYZ).....                   | 21    |
| Gas Conversion for Modulator – PART C.....  | 22    |
| Millivolt System, Lighting, and Burner Control.....                                       | 23    |
| Lighting Instructions for Millivolt Valve with 7 Day Timer.....                           | 24    |
| Electronic Ignition Lighting Instructions.....  | 25    |
| Troubleshooting the Gas Control System.....   | 26    |
| <b>PROFLAME 2</b>   |       |
| Proflame 2- Parts List.....   | 27    |
| IFC Module and Remote Control.....  | 28    |
| Cold Climates – CPI Setting - Proflame 2 Remote Control.....                              | 29    |
| Remote Flame Control, Room Thermostat.....  | 30    |
| Smart Thermostat, Fan Speed Control, Remote Dimmer Control.....                           | 31    |
| Proflame 2 Schematic.....   | 32    |
| WMBH – Wall Mount Battery Holder – Option.....  | 33    |
| <b>PROFLAME 1</b>   |       |
| IPI Electronic Ignition System.....   | 34    |
| Remote Control Operation.....   | 35    |
| IPI Electronic Ignition Parts List – Standard System.....                                 | 36    |
| Configuration 1: Basic Manual Hi / Lo and manual Off.....                                 | 37    |
| Configuration 2: Remote On / Off and manual Hi / Lo.....                                  | 38    |
| Operating the Receiver Without Batteries For GT / EGT / GTM / EGTM Remote Controls.....   | 39    |
| Configuration 3: Remote ON/OFF, Variable HI/LO, and Fan.....                              | 40    |
| <b>VENTING</b>  |       |
| Vent Terminal Clearances.....   | 41    |
| General Venting Information.....  | 42    |
| Venting Routes and Components.....  | 43-44 |
| Horizontal Vent Installation.....   | 45    |
| Horizontal Snorkel Terminations.....  | 46    |

|  |       |
|--|-------|
| Vertical Venting Over 15 Feet.....         | 47    |
| Vertical Vent Installation.....            | 48-49 |
| <b>PARTS LIST</b>                          |       |
| FDV200S Parts List.....                    | 50-51 |
| <b>WARRANTY</b>                            |       |
| Glass Safety / Termination Cap Safety..... | 52    |
| Limited Lifetime Warranty.....             | 53    |

## FDV200S Safety Screen Attachment / Removal

### **INSTALLATION:**

1. Insert top of Screen Frame into bottom of stove top.
2. Engage Top Hooks into Top Slots.
3. Engage Bottom Hooks into Bottom Slots.



To remove Safety Screen, ***Wait Until Fireplace is Completely Cool***, and reverse these steps.



## Pre-installation Questions and Answers

### About curing of the paint

Your stove or fireplace has been painted with the highest quality silicone stove paint. This paint dries quickly in 15-20 minutes when first applied at the factory. However, due to the high temperature silicone components, the paint will cure when heat is applied to the appliance as it is first used. The following information applies to the curing process to get the paint fully hard and durable. **Note: Use of painter's tape is not recommended, as it may damage the paint.**

Fire the appliance four successive times for 10 minutes each firing and a 5 minute cool down between each. Be aware during log and firebox paint curing that a white deposit may be developing on the inside of the glass doors. It is important to remove this white deposit from the glass doors using a fireplace glass cleaner.

- Babies, small children, pregnant women and pets should leave the area during the cure phase.
- Ventilate well, open doors and windows.
- Do not touch during curing.

### Why does my fireplace or stove give off odor?

It is normal for your fireplace to give off some odor at first. This is due to the curing of the paint, adhesives, silicones and any undetected oil from the manufacturing process as well as the finishing materials used with the installations (e.g. marble, tile and the adhesives used to adhere this product to the walls can react with heat and cause odors).

It is recommended that you burn your gas fireplace or stove for a minimum of four hours at a time with the fan off (if a fan is present) after the curing of the paint has been completed. These odors can last upward to 40 hours of burn time; keep burning at a minimum of four hours per use until odors dissipate.

### Noise coming from the fireplace?

Noise is caused by the expansion and contraction of metal as the appliance heats up and cools down. This is normal and is similar to the sounds produced by a furnace or heating duct. This noise does not affect the operation or longevity of your fireplace.

It is also normal for the fan to make some noise when it comes on. This noise can be reduced somewhat by turning down the speed of the fan with the variable speed control. Be aware, however, that this will reduce the volume of heated air circulated into the room by the fan.

### Note to the Installer:

Be sure appliance is working properly and its operation (including remote control operation, if included) is fully explained to and understood by the customer.

## Operations and Maintenance Instructions

For safe installation and operation note the following:

- Be sure to read and understand all the instructions in this manual before operation of appliance.
- Ensure all wiring is correct and properly enclosed to prevent possible shock.
- Check for gas leaks.
- Make sure the glass door is properly installed before operation. Never operate the appliance with the glass door removed.
- Make sure venting and termination cap are installed and unobstructed.
- If brick or porcelain liners are used, ensure they are installed.
- Verify that the pilot can be seen when lighting the appliance. If not, the log or rock placement is incorrect.
- If the unit is turned off, you must wait a minimum of 60 seconds before re-lighting it.
- Venting systems should be periodically examined by a qualified agency.
- The flow of combustion and ventilation air must not be obstructed.
- The Burner/Log Assembly has been engineered and permanently adjusted for proper flame control.
- Periodically remove the logs from the grate assembly and vacuum any loose particles from the grate and burner areas. See Log Placement page to remove logs. Vacuum burner parts and replace logs.
- Never use your gas fireplace as a cooking device.
- Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.
- Areas in and around the Chase Vent Openings should be cleaned annually.

## Annual Inspection List for Determining Safe Operation of a Direct Vent Gas Fireplace


Refer to this checklist for proper maintenance, safe use, and operation.

See each section for more specific information.


1. Inspect and operate all pressure relief mechanisms (i.e., relief dampers, spring loaded door latches) installed on your appliance to verify relief mechanisms are free from obstruction to operate.

Relief Dampers inside Firebox should open and close freely.


Upper Damper




Upper Damper



Lower Damper




Upper Door Latch



Spring loaded Door Latches should extend and return to the closed position.

Lower Door Latch




2. Clean glass window with a suitable fireplace glass cleaner. Abrasive cleaners must not be used. Be careful not to scratch the glass when cleaning.

3. Inspect the operation of the Pilot. Ensure that it is working properly.

Pilot Orientation  
(Top View)

Burner




Inspect Pilot Flame



4. Inspect and ensure the lighting of the main burner occurs within 4 seconds of the main gas valve opening. Visual inspection should match that outlined in the appliance instruction manual (refer to **Monthly Flame Inspection**). Inspect primary air openings for blockage.

Primary Air Opening  
Inspect for Blockage



5. Inspect condition of vent and vent terminal for sooting or obstruction and correct if present.
6. Vacuum and clean any debris in the firebox that is not supposed to be there.
7. Test and measure the flame failure response time of the flame safety system. It must de-energize the safety shutoff in no more than 30 seconds.  
**Procedure for Millivolt Units:** Turn on fireplace for 5 minutes. Shut off fireplace while listening to valve. A "click" should be heard within 30 seconds. This indicates the safety shutoff is working properly.  
**Procedure for IPI Units:** Turn on fireplace and allow main burner to come on. Then disconnect Flame Sense wire from IPI Module (X3 Connection). The fireplace should shut down immediately.
8. Check all accessible gas-carrying tubes, connections, pipes and other components for leaks.

## Warnings, Installations and Operations - Installation Regulations

This gas appliance must be installed by a qualified installer in accordance with local building codes, or in the absence of local codes, with the current CAN/CSA-B149.1 or .2 Installation Code (in Canada) or the current National Fuel Gas Code Z223.1- NFPA 54 when installed in the United States.

This appliance, when installed, must be electrically connected and grounded in accordance with local codes, or in the absence of local codes, with the current CSA C22.1 Canadian Electrical Code or with the National Electrical Code; ANSI/NFPA 70 when installed in the United States.



**FOR SAFE INSTALLATION AND OPERATION OF YOUR GAS FIREPLACE PLEASE NOTE THE FOLLOWING:**

1. Do not clean when the glass is hot.
2. Do not use abrasive cleaners.
3. Using a substitute glass will void all product warranties.
4. For safe operation, glass doors must be closed.
5. When purging the gas line, the glass front must be removed.
6. Do not strike or abuse glass. Take care to avoid breakage.
7. Do not alter gas orifice.
8. No substitute materials may be used other than factory supplied components.
9. This appliance gives off high temperatures and should be located out of heavy traffic areas and away from furniture and draperies.
10. Children and adults should be alerted to the hazards of the high surface temperatures of this appliance and should stay away to avoid burns or ignition of clothing.
11. Young children should be carefully supervised when they are in the same room as the appliance. Toddlers, young children and others may be susceptible to accidental contact burns. A physical barrier is recommended if there are at risk individuals in the house. To restrict access to a fireplace or stove, install an adjustable safety gate to keep toddlers, young children and other at risk individuals out of the room and away from hot surfaces.
12. Under no circumstances should any solid fuels (wood, paper) be used in this appliance.
13. Under no circumstances should this appliance be modified. Any parts that have to be removed for servicing should be replaced prior to operating this appliance.
14. Any safety screen, guard, or barrier removed for servicing an appliance must be replaced prior to operating the appliance.
15. Installation and repair should be done by a qualified service person. The appliance should be inspected before use and at least annually by a professional service person. More frequent cleaning may be required due to excessive lint from carpeting, bedding material, et cetera. It is imperative that control compartments, burners and circulating air passageways of the appliance be kept clean. Make sure that the gas valve and pilot light are turned off before you attempt to clean this unit.
16. Clothing or other flammable material should not be placed on or near the appliance. This appliance should not be used as a drying rack for clothing nor should Christmas stockings or decorations be hung from it.
17. Do not use this heater if any part has been under water. Immediately call a qualified service technician to inspect the heater and to replace any part of the control system and any gas control which has been under water.
18. Do not operate appliance unless completely installed as per installation instructions.
19. Failure to position the parts in accordance with these diagrams or failure to use only parts specifically approved with this appliance may result in property damage or personal injury.
20. **WARNING: Do not operate appliance with the glass front removed, cracked or broken. Replacement of the glass should be done by a licensed or qualified service person.**
21. The appliance area must be kept clear and free from combustible materials, gasoline, and other flammable vapors and liquids.
22. The front of the fireplace gives off high temperatures that could ignite combustible material which is kept close to the front of the unit.
23. Ensure that power to the Fireplace is turned off before servicing.
24. Do not operate this Fireplace without the glass front or with a broken glass.
25. Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the owner's information manual provided with this appliance. For assistance or additional information consult a qualified installer, service agency, or the gas supplier.
26. Operation of this appliance when not connected to a properly installed and maintained venting system or tampering with the blocked vent shutoff system can result in carbon monoxide (CO) poisoning and possible death.
27. This appliance is equipped with a three-prong (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle. Do not cut or remove the grounding prong from this plug.
28. **NOT INTENDED FOR USE AS A PRIMARY HEAT SOURCE.** This appliance is tested and approved as either supplemental room heat or as a decorative appliance. It should not be factored as primary heat in residential heating calculations.
29. This appliance must not be connected to a chimney flue serving a separate solid-fuel burning appliance.

## Installation Requirements for the Commonwealth of Massachusetts

In the Commonwealth of Massachusetts, the installer or service agent shall be a plumber or gas fitter licensed by the Commonwealth.

When installed in the Commonwealth of Massachusetts or where applicable codes; the unit shall be installed with a CO detector per the requirements listed below.

1. For direct-vent appliances, mechanical-vent heating appliances or domestic hot water equipment, where the bottom of the vent terminal and the air intake is installed below four feet above grade the following requirements must be satisfied:
  - A. If there is not one already present, on each floor level where there are bedroom(s), a carbon monoxide detector and alarm shall be placed in the living area outside the bedroom(s). The carbon monoxide detector shall comply with NFPA 720.
  - B. A carbon monoxide detector shall be located in the room that houses the appliance or equipment and shall:
    - Be powered by the same electrical circuit as the appliance or equipment such that only one service switch services both the appliance and the carbon monoxide detector;
    - Have battery back-up power;
    - Meet ANSI/UL 2034 Standards and comply with NFPA 720; and
    - Have been approved and listed by a Nationally Recognized Testing Laboratory as recognized under 527 CMR.
  - C. A Product-approved vent terminal must be used, and if applicable, a Product-approved air intake must be used. Installation shall be in strict compliance with the manufacturer's instructions. A copy of the installation instructions shall remain with the appliance or equipment at the completion of the installation.
  - D. A metal or plastic identification plate shall be mounted at the exterior of the building, four feet directly above the location of vent terminal. The plate shall be of sufficient size to be easily read from a distance of eight feet away, and read "Gas Vent Directly Below".
2. For direct-vent appliances, mechanical-vent heating appliances or domestic hot water equipment where the bottom of the vent terminal and the air intake is installed above four feet above grade the following requirements must be satisfied:
  - A. If there is not one already present, on each floor level where there are bedroom(s), a carbon monoxide detector and alarm shall be placed in the living area outside the bedroom(s). The carbon monoxide detector shall comply with NFPA 720.
  - B. A carbon monoxide detector shall:
    - Be located in the room that houses the appliance or equipment;
    - Be either hard-wired or battery powered or both; and
    - Shall comply with NFPA 720.

A Product-approved vent terminal must be used, and if applicable, a Product-approved air intake must be used. Installation shall be in strict compliance with the manufacturer instructions. A copy of the installation instructions shall remain with the appliance or equipment at the completion of the installation.

For the state of Massachusetts a **T-handle gas shut-off valve** must be used on a gas appliance. This T-handle gas shut-off valve must be listed and approved by the state of Massachusetts. This is in reference to the state of Massachusetts state code CMR238.


## Carbon Monoxide (CO) Detector

NOTE: It is recommended that a Carbon Monoxide (CO) Detector be installed in or near bedrooms and on all levels of your home. Place a detector about 15ft [4.5m] outside the room that houses your gas appliance.

Certified for installation in a bedroom or bed/sitting room. In Canada must be installed with listed millivolt thermostat. In USA see local codes.

## Mobile Home/Manufactured Housing Installation

This Direct Vent System Appliance must be installed in accordance with the manufacturer's installation instructions and the Manufactured Home Construction and Safety Standard Title 24 CFR, Part 3280, or the current Standard for Fire Safety Criteria for Manufactured Home Installations, Sites, and Communities ANSI/NFPA 501A, and with CAN/CSA Z240 MH Mobile Home Standard in Canada.



THE VENTED GAS FIREPLACE HEATERS (ANSI Z21.88) IN THIS MANUAL MAY BE INSTALLED IN MANUFACTURED (MOBILE) HOMES AFTER FIRST SALE IN THE USA.

THE VENTED GAS FIREPLACE HEATERS (ANSI Z21.88) IN THIS MANUAL MAY BE INSTALLED IN MANUFACTURED (MOBILE) HOMES IN CANADA.

Please follow the current ANSI/NFPA 70 National Electrical Code in the USA and CAN/CSA C22.1 Canadian National Electrical Code in Canada.


An appliance must be grounded to the steel chassis of the home with 8 ga. copper wire using a serrated or star washers to penetrate paint or protective coating to insure grounding.  
Use carriage bolt at the attachment point (see diagram above) to secure the appliance to the floor.

**⚠ Warning:** Do not compromise the structural integrity of the manufactured home wall, floor or ceiling, during installation of appliance or venting.

**For required venting components see venting installation in appropriate section of this manual.**


Certified for installation in a bedroom or bed/sitting room. In Canada must be installed with listed millivolt thermostat. In USA see local codes.

## FDV200S Dimensions



Gas Inlet is located at the back of the unit.

## FDV200S Locating Your Appliance




The unit should be placed on a hard, stable surface. Appliance may be installed directly on carpeting, tile or other combustible material with no additional floor protection being required.


**This unit has been tested in an Alcove. Minimum Dimensions of Alcove are as follows:**  
**Depth 30", Height 55.5", Width 52.5".**

# FDV200S Component Locations


## MILLIVOLT




### BOTTOM VIEW




## PROFLAME 1




### BOTTOM VIEW



## PROFLAME 2



### BOTTOM VIEW







## FDV200S



## Component Cover

The Component Cover is located directly below the Control Panel.

**⚠ WARNING:** Wait until unit is **COMPLETELY** cool before attempting to install or remove components.




### To Remove Component Cover:



Remove the [2] DT screws at the front of the Component Cover. Next Carefully remove the Rear Tabs from the unit.

### To Install Component Cover:



Hook the Rear Tabs over the back of the Component Tray. Next attach front of Component Cover with [2] DT screws.



# Fan Installation F45FK - FDV200S Millivolt and Proflame 1 Units

## ⚠ WARNING


### Electrical Grounding Instructions

This appliance is equipped with a three prong (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle. Do not cut or remove the grounding prong from this.


### Before Servicing

1. Ensure all power supply is shut off.
2. Label all wires prior to disconnecting when servicing control. Wiring errors can cause improper and dangerous operation.
3. For fan servicing: Vacuum and clean lint/dirt build-up on the fan blades and motor.


## WIRING SCHEMATIC



**Note:** It is easier (but not required) to install the fan kit with the unit elevated.



1. Remove Fan Cover.




2. Insert fan wires into hole as shown. Mount fan onto the [2] screws on the back of the fireplace using the keyholes on the fan housing.

Insert fan wires into hole as shown. See **BACK LEFT OF UNIT** view below.

## BACK LEFT OF UNIT



Insert fan wires into hole as shown.




Thermodisc

Variable Speed Switch

Variable Speed Switch wire connections

3. Connect the Thermodisc on the fireplace to fan wires with black insulated connectors. Install variable speed switch and connect to red plastic connectors.

4. Replace Fan Cover.



## Fan Speed Control Outside of Fireplace

If you plan to locate the variable speed control switch for the fan outside of the fireplace and you require a constant source of AC power inside the unit for another accessory such as lights or an IPI valve system, follow one of the procedures below.

### ⚠ WARNING

A qualified electrician must connect electrical wiring to junction outlet for built-in installation.

**Follow all codes.**

### ⚠ WARNING


**Electrical Grounding Instructions –**  
This appliance is equipped with a three – pronged (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle.

### ⚠ WARNING


Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation and servicing.

**⚠ Caution:** Electrical installation to be done by a qualified installer. All wires must be connected and grounded in accordance with CSA Standard C22.1- Canadian Electrical Code part 1 or with the National Electrical Code, ANSI /NFPA 70 (latest edition) and /or in accordance with local codes.

Switch Controlled Split Receptacle With Switch At START Of Cable Run




Switch Controlled Split Receptacle With Switch At END Of Cable Run






## FDV200RL Brick Liner Installation




### Installation of Brick Panel Kit:

1. Remove glass door as shown in door removal diagram.
2. Place Back Brick Panel up to rear of firebox, leaving bottom of panel slightly forward for support.
3. Remove left and right Brick Clips using a 1/4" nut driver. Do not discard Brick Clips.
4. Reposition Brick Clips onto left and right Brick Panels and reinstall.
5. Install log set and glass door.



**⚠ WARNING:** Failure to position the parts in accordance with these diagrams or failure to use only parts specifically approved with this appliance may result in property damage or personal injury.



#### Step 1:

**Log 1** is installed onto Locating Tabs 1A and 1B as shown.



#### Step 2:

The hole in the bottom of **Log 2** is placed onto Locating Tab 2A. The long branch of Log 2 is placed onto notched area of Log 1 as shown.



#### Step 3:

Place **Log 3** into position as shown. Slide Log 3 forward up to Locating Tabs 3A and 3B.

**Do not** place Log 3 on top of Locating Tabs.



#### Step 4:

Place **Log 4** onto notched areas of Log 1 and Log 3.




#### Step 5:

Place **Log 5** up against the 2nd Grate Bar from the left as shown.



#### Step 6:

Place Glowing Ember Chunks onto front Burner Tube and slotted Ember Plate. Do not place Chunks on rear Burner Tube.



## Door and Glass Information FDV200S

### Glass Cleaning

It will be necessary to clean the glass periodically. During startup, condensation, which is normal, forms on the inside of the glass, and causes dust, lint etc. to cling to the glass surface.

Also, initial paint curing can deposit a slight film on the glass. It is therefore recommended that initially the glass be cleaned two or three times with a fireplace glass cleaner. After that, the glass should be cleaned two or three times a season depending on the circumstances.



### Cautions and Warnings

- Do not clean when the glass is hot.
- The use of substitute glass will void all product warranties (see **Glass Replacement** in this section).
- Care must be taken to avoid breakage of the glass.
- Do not operate this fireplace without the glass front or with a broken glass front.
- Do not strike or abuse the glass.

### Glass Replacement


Only Robax ceramic or coated Neoceram glass may be used for replacement for all FDV200S Models. Glass must be minimum 5mm thick.

To replace glass, clean all materials from the door frame. Scrape off old silicone all the way down to the metal. Using high-temp silicone [rated up to 500°F (260°C)] apply a continuous bead of approximately 1/8"-3/16" to all four [4] sides of the frame. With the frame resting on a flat surface, insert the new glass with a new gasket. Gently press the glass into the silicone. Be careful not to use excessive force on the glass. Let the silicone dry for approximately 15-20 minutes.

**Use caution when removing broken glass. Wear gloves.**

### Removal of the Glass Front Door


1. Remove the two screws at the top of door.
2. Pull top of door forward and lift from bottom retainer.
3. To re-install, reverse steps one and two.



## Gas Line Installation

This gas appliance should be installed by a qualified installer in accordance with local building codes and with current CAN/CGA - B149.1 or .2 installation codes for Gas Burning appliances and equipment in Canada and the National Fuel Gas Code ANSI Z223 in the U.S.A.

1. The gas pipeline can be brought in through the back or bottom of the unit.
2. The gas control inlet is 3/8" NPT. Typical installation layout for rigid pipe is shown at right.
3. When using copper or flex connector, use only approved fittings. Always provide a union so that gas line can be easily disconnected for burner or fan servicing. See gas specification for pressure details and ratings.
4. When a vertical section of gas pipe is required for the installation, a condensation trap is needed. See CAN/CGA-B149.1 or .2 for code details.
5. For natural gas, a minimum of 3/8" iron pipe with gas minimum pressure of 4.5" w.c. must be used for supply from the gas meter. Consult with the local gas utility if any questions arise concerning pipe sizes.
6. A 1/8" NPT plugged tapping is accessible for test gauge connection both on the inlet and outlet of the gas valve.
7. Turn the gas supply ON and check for leaks. **DO NOT USE OPEN FLAME FOR THIS PURPOSE.** Use an approved leak testing solution.
8. The appliance and its individual shutoff valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 PSIG (3.5 KPa).
9. The appliance must be isolated from the gas supply piping system by closing its individual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 PSIG (3.5 KPa).



**NOTE:** The gas line connection may be made of 1/2" rigid pipe or an **Approved Kingsman Flex Connector, such as FP15GC.** Since some municipalities have additional local codes, it is always best to consult your local authorities and the current CAN/CGA - B149.1 or .2 installation code in Canada or the National Fuel Gas code ANSI Z223.1 in the U.S.A

For the state of Massachusetts a T-handle gas shut-off valve must be used on a gas appliance. This T-handle gas shut-off valve must be listed and approved by the state of Massachusetts. This is in reference to the state of Massachusetts state code CMR238.

Important: Always check for gas leaks with a soap and water solution. Do not use open flame for leak testing.

Shutoff valves installed in tubing systems shall be rigidly and securely supported independently of the tubing.

## Gas Specifications

| MODELS                                   | FDV200SN              | FDV200SNE<br>FDV200SNE2 | FDV200SLP  | FDV200SLPE<br>FDV200SLPE2 |
|--|-----------------------|-------------------------|------------|---------------------------|
| Fuel                                     | Natural               | Natural                 | Propane    | Propane                   |
| Gas Control                              | Millivolt             | IPI                     | Millivolt  | IPI                       |
| Maximum                                  | 28,500                | 28,500                  | 26,000     | 26,000                    |
| Low                                      | 19,500                | 19,500                  | 20,000     | 20,000                    |
| Orifice Size<br>(0-4500ft)               | #35                   | #35                     | 1/16"      | 1/16"                     |
| Air Shutter                              | 3/8"                  | 3/8"                    | Fully Open | Fully Open                |
| Gas Inlet Size S.I.T. 820 Nova, 3/8" NPT |                       |                         |            |                           |
| Gas Supply Pressure                      | Minimum               |                         | Normal     | Maximum                   |
| Natural Gas                              | 5.5"                  |                         | 7"         | 9"                        |
| Propane                                  | 11"                   |                         | 11"        | 12"                       |
| Manifold Pressure                        | Natural Gas           |                         |            | Propane                   |
| Manifold Pressure High                   | 3.5 IN. W.C./ .87 KPa |                         |            | 10 IN. W.C./ 2.61 KPa     |
| Manifold Pressure Low                    | 1.6 IN. W.C./ .40 KPa |                         |            | 6.3 IN. W.C./ 1.57 KPa    |



## Burner System Maintenance

It is recommended to annually inspect and clean the Burner System to prevent malfunction and / or sooting. This operation should be performed by your dealer or a qualified technician.

### **⚠ -CAUTION-**

Before servicing the burner system ensure that the gas supply is turned OFF and disconnect all electrical connections to the appliance. Allow the appliance to cool to room temperature. Note that the pilot assembly may be hot in an intermittent or standing-pilot system—even if the main burner was never on. Exercise caution when working within the area.


**-ALL WORK SHOULD BE PERFORMED BY A QUALIFIED AND CERTIFIED TECHNICIAN-**

### Monthly Flame Inspection

It is recommended to turn on the unit at least once a month and inspect the flame pattern to ensure there are no problems with the burner tube. The pilot flame should also be inspected monthly to ensure proper operation.



Flame should appear similar to the above picture.




Pilot Must Maintain This Relationship With Burner Tube.

## Conversion Kit Instructions – PART A

| Kit Number                          | Description                            | Pilot Orifice                | Burner Orifice<br>Brass (1000-255) | Brass Nipple    | Air<br>Shutter | Hi/Lo<br>Regulator         |
|-------------------------------------|--|------------------------------|------------------------------------|-----------------|----------------|----------------------------|
| <b>200DV-CKLP</b><br>(FDV200SLP)    | Propane<br>Conversion<br>-Millivolt-   | 1001-P167SI<br>#30 (977.167) | 1/16"                              | 1000-253 closed | Full<br>Open   | 1001-P202SI<br>(0.907.202) |
| <b>200DV-CKNG</b><br>(FDV200SN)     | NG Conversion<br>-Millivolt-           | 1001-P165SI<br>#51 (977.165) | #35                                | 1000-253 closed | 3/8"           | 1001-P201SI<br>(0.907.201) |
| <b>200DV-CKLP1</b><br>(FDV200SLPE)  | Propane<br>Conversion<br>-Proflame 1 - | 1001-P168SI<br>#35 (977.168) | 1/16"                              | 1000-253 closed | Full<br>Open   | 1002-P014SI<br>(0.907.014) |
| <b>200DV-CKNG1</b><br>(FDV200SNE)   | NG Conversion<br>- Proflame 1-         | 1001-P166SI<br>#62 (977.166) | #35                                | 1000253 closed  | 3/8"           | 1002-P016SI<br>(0.907.016) |
| <b>200DV-CKLP2</b><br>(FDV200SLPE2) | Propane<br>Conversion<br>-Proflame 2 - | 1001-P168SI<br>#35 (977.168) | 1/16"                              | 1000-253 closed | Full<br>Open   | 1002-P012SI                |
| <b>200DV-CKNG2</b><br>(FDV200SNE2)  | NG Conversion<br>- Proflame 2-         | 1001-P166SI<br>#62 (977.166) | #35                                | 1000253 closed  | 3/8"           | 1002-P013SI                |

Refer to "Gas Specifications Chart" for inlet pressures and input ratings. Clock meter to verify input rate. Place conversion label as close to converted gas control as possible. Refer to lighting instructions to verify the normal operating sequence of the ignition system. **IMPORTANT: Always check for gas leaks with a soap and water solution. DO NOT USE OPEN FLAME FOR LEAK TESTING.**

## Conversion Kit Instructions – Part A



### Parts List:

- HI/LO Pressure Regulator Assembly
- Burner Orifice
- Brass Nipple
- Instructions
- Conversion Kit Label
- Pilot Orifice

### ⚠ Caution:

The gas supply shall be shut off prior to disconnecting the electrical power, before proceeding with the conversion.

1. The Burner Tube must be removed from the Burner Pan Assembly (see above). Adjust the Air Shutter to the correct Primary Air setting as specified in the manual or on the label plate. To adjust the Primary Air setting, loosen screw on the side of the Air Shutter and rotate to the correct opening using a drill bit or tape measure. Retighten screw.
  2. Remove the Main Orifice using a 1/2" wrench and replace with the new Conversion Orifice which came with the Conversion Kit.
  3. Replace the Burner Tube. Install the new Pilot Orifice (See **Pilot Conversion**) and Hi/Lo valve regulator by following instructions supplied with the Conversion Kit.
- Refer to **Gas Specifications Chart** for inlet pressures and input ratings.
  - Clock meter to verify input rate.
  - Place conversion label as close to converted gas control as possible.
  - Refer to **lighting instructions** to verify the normal operating sequence of the ignition system.
  - Refer to **Burner System Maintenance** for proper relationship of the pilot flame to the main burner and for main burner flame appearance.

### -⚠ Warning-

This conversion kit shall be installed by a qualified service agency in accordance with the manufacturer's instructions and all applicable codes and requirements of the authority having jurisdiction. If the information in these instructions is not followed exactly, a fire, explosion or production of carbon monoxide may result causing property damage, personal injury or loss of life. The qualified service agency is responsible for the proper installation of this kit. The installation is not proper and complete until the operation of the converted appliance is checked as specified in the manufacturer's instructions supplied with the kit.





Instructions for converting SIT 190 series pilot burner injector from NG to PROPANE and from PROPANE to NG only. This information should be considered as supplemental to the Appliance Manufacturer's Instructions.

**WARNING! The installation of this conversion kit must only be undertaken by a qualified and certified gas appliance installer.**

1. Shut-off the gas supply to the appliance.
2. Allow the pilot burner to cool to room temperature.

**WARNING: Touching a hot pilot burner can result in injury.**

3. The pilot hood is held in place by spring. First remove the spring, then remove the hood by pulling it up from the pilot bracket (fig. 1).
4. Insert a 5/32" or 4 mm Allen wrench into the hexagonal key-way of the injector (fig. 2), and rotate it counter-clockwise until it is free of the injector journal.
5. Verify that the new injector is proper for the application. The injector size is stamped on the side of the injector near the top. Propane injectors have a groove machined around their circumference near the top, while NG injectors do not have a groove (fig. 4). Refer to the Appliance Manufacturer's instruction sheet for the proper injector size.
6. Insert the Allen wrench into the end of the injector. Then, insert the injector into injector journal, and rotate the injector clockwise until a torque of 9 lbf in (1.0 Nm) is achieved.
7. First replace the pilot hood by aligning the tab on the base of the hood with the slot in the side of the pilot journal, and push the hood down, onto the pilot bracket (fig. 3). The hood must sit squarely on the bracket for proper operation. Then replace the spring by pushing it on his seat (fig.3). Check to insure that the hood is properly seated onto the pilot bracket and that the spring is properly inserted onto his seat.
8. Restore the gas supply to the appliance, and ignite the pilot burner. Verify proper ignition and operation.




fig. 1




fig. 2




fig. 3




fig. 4

### WARNING!

This conversion kit must **ONLY** be applied as part of a conversion kit supplied by the **APPLIANCE MANUFACTURER** for the specific appliance, and type of gas, being converted.



# SIT GROUP

www.sitgroup.it

7.252.136

# installation instructions

## 820 NOVA mV

### Modulating Conversion Kit




#### WARNING!

The installation of this conversion kit must only be undertaken by a qualified and certified gas appliance installer.

#### MODULATING PRESSURE REGULATOR CONVERSION KIT INSTALLATION OR REPLACEMENT INSTRUCTIONS.

- 1 Turn control knob to the OFF position, and shut off the gas supply to the valve.
- 2 Using a Torx T20, or slotted screwdriver, remove and discard the three pressure regulator mounting screws (A), pressure regulator tower (B), and the spring and diaphragm assembly (C).  
(If applicable)
- 3 Insure that the rubber gasket (D) is properly positioned and install the new modulating pressure regulator assembly to the valve using the new screws (E) supplied with the kit. Tighten screws securely.  
(Reference torque = 25 In.Lb.)
- 4 Install the enclosed identification label (F) to the valve body where it can be easily seen.
- 5 Apply gas to system and re-light appliance according to manufacturers instructions.
- 6 With the main burner "ON", test the new pressure regulator assembly for leaks using a soap solution.
- 7 Relight the main burner in both the HI and LO positions, and verify proper burner ignition and operation.



#### WARNING!

This modulating conversion kit must ONLY be applied as part of a conversion kit supplied by the APPLIANCE MANUFACTURER for the specific appliance, and type of gas, being converted.

**INSTALLER NOTICE.** These instructions must be left with appliance.



**SIT Group**

# Millivolt System, Lighting, and Burner Control

## FOR YOUR SAFETY READ BEFORE LIGHTING



**WARNING:** If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

### BEFORE LIGHTING

- |  |  |
|--|--|
| <p>A This appliance has a pilot which must be lighted by hand. When lighting the pilot, follow these instructions exactly.</p> <p>B Smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.</p> | <ul style="list-style-type: none"> <li>Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions.</li> <li>If you cannot reach your gas supplier, call the fire department.</li> </ul> <p>C Use only your hand to push or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it. Call a qualified technician. Force or attempted repair may result in a fire or explosion.</p> <p>D Do not use the appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system which has been under water.</p> |
|--|--|

### WHAT TO DO IF YOU SMELL GAS

- Do not try to light an appliance.
- Do not touch any electrical switch; do not use any phone in your building.

## LIGHTING INSTRUCTIONS

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>Stop! Read the safety information above this label.</li> <li>Set the thermostat to lowest setting.</li> <li>Turn off all electrical power to the appliance.</li> <li>Locate valve under the burner assembly.</li> <li>If the control knob is not already in the off position, i.e. the word "OFF" in the 9 o'clock position, then push in the gas control knob slightly and turn ⤵ clockwise to "OFF". NOTE: Knob cannot be turned from "PILOT" to "OFF" unless knob is pushed in slightly. Do not use force.</li> <li>Wait five [5] minutes to clear out any gas. If you then smell gas. STOP! Follow "B" in the safety information above on this label. If you don't smell gas then go to the next step.</li> <li>Now push in the control knob slightly and turn ⤵ counter-clockwise to the "PILOT" position.</li> <li>Push in the control knob all the way and hold it. With the other hand push in the red igniter button until you hear a click. Now observe closely the pilot burner located on the rear center-left hand side of the main burner.</li> </ol> | <p>If a flame has appeared then continue to depress the control knob for 20 seconds. If the flame did not appear then continue to depress the red igniter button every 5 seconds until a flame is established. NOTE: If after 30 seconds a flame has not yet been established then turn the control knob back to the off position and repeat steps 5, 6 &amp; 7.</p> <ol style="list-style-type: none"> <li>Once the pilot has been established hold the control knob in the depressed position for approximately 25 seconds before releasing. If the flame goes out then repeat steps 7 and 8. <ul style="list-style-type: none"> <li>If the knob does not pop up when released, stop and immediately call your service technician or gas supplier.</li> <li>If the pilot will not stay lit after several tries, turn the gas control to "OFF" and call your service technician.</li> </ul> </li> <li>Now turn the control knob to the "ON" position. The burner will not light unless the wall switch thermostat or remote control is turned "ON" or in the case of the thermostat there is a call for heat.</li> <li>Close the access door and turn all electrical power back to the appliance.</li> </ol> |
|--|---|

## TO TURN OFF THE APPLIANCE


- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>Set the thermostat to lowest setting.</li> <li>Turn off all electric power to the appliance if service is to be performed.</li> <li>Open the control access door.</li> </ol> | <ol style="list-style-type: none"> <li>Push in the gas control knob slightly and turn ⤵ clockwise to the "OFF" position. Do not force.</li> <li>Replace control access panel.</li> </ol> |
|---|--|

**NOTE:** Only one on/off device (manual on/off, remote control, or hard wired thermostat) should be connected to the appliance at any one time, this is most important when installing an insert or stove as the on/off rocker switch is installed at the factory.

Recommended Maximum Lead Length (Double Wire)  
When Using Wall Switch or Thermostat

| Wire Size | Max. Length   |
|-----------|---------------|
| 14ga      | 100ft [30.4m] |
| 16ga      | 64ft [19.5m]  |
| 18ga      | 40ft [12.1m]  |
| 20ga      | 25ft [7.6m]   |
| 22ga      | 15ft [4.5m]   |

**CAUTION: DO NOT WIRE 120V POWER TO MILLIVOLT SWITCHES OR THERMOSTAT.**



## - Lighting Instructions for Millivolt Valve with 7 Day Timer -

### FOR YOUR SAFETY READ BEFORE LIGHTING

**WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.**

- A. This appliance has a pilot which must be lighted by hand. When lighting the pilot, follow these instructions exactly.
- B. **BEFORE OPERATING** smell around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

#### WHAT TO DO IF YOU SMELL GAS


- Do not try to light any appliance.
- Do not touch any electric switch; do not use any phone in your building.
- Leave the building immediately.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.

- If you cannot reach your gas supplier, call the fire department.
- C. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and replace any part of the control system and any gas control which has been under water.
- D. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, do not try to repair it; call a qualified service technician. Force or attempted repair may result in a fire or explosion.

### OPERATING INSTRUCTIONS

1. **Stop!** Read the safety information above on this label.
2. This appliance is equipped with an on-demand pilot that shuts off after 7 days.
3. Set the thermostat to lowest setting.
4. Turn off all electric power to the appliance.
5. Locate valve under the burner assembly.
6. If the control knob is not already in the off position, i.e. the word "OFF" in the 9 o'clock position, then push in the gas control knob slightly and turn ⤵ clockwise to "OFF". NOTE: Knob cannot be turned from "PILOT" to "OFF" unless knob is pushed in slightly. Do not use force.

Gas Control knob shown in "PILOT" position



7. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, STOP! Follow "B" in the safety information above this label. If you do not smell gas, go to next step.
8. Now push in the control knob slightly and turn ⤵ counter-clockwise to the "PILOT" position.

9. Push in the control knob all the way and hold it. With the other hand push in the red igniter button until you hear a click. Now observe closely the pilot burner located on the rear center-left hand side of the main burner. If a flame has appeared then continue to depress the control knob until a BEEP is heard. This procedure may take up to TWO MINUTES.
10. If the pilot flame did not appear then continue to depress the red igniter button every 5 seconds until a flame is established. NOTE: If after 30 seconds a flame has not yet been established then turn the control knob back to the off position and repeat steps 7, 8, and 9.
11. Once the pilot has been established hold the control knob in the depressed position for approximately 25 seconds before releasing. If the flame goes out then repeat steps 9 and 10.
  - If the knob does not pop up when released, stop and immediately call your service technician or gas supplier.
  - If the pilot will not stay lit after several tries, turn the gas control to "OFF" and call your service technician.
12. Now turn the control knob to the "ON" position. The burner will not light unless the wall switch thermostat or remote control is turned "ON" or in the case of the thermostat there is a call for heat.
13. Close the access door.
14. Turn on all electric power to the appliance.
15. Set thermostat to desired setting.
16. If the appliance will not operate, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.

### TO TURN OFF GAS TO APPLIANCE

1. Set thermostat to lowest setting.
2. Turn off all electric power to the fireplace if service is to be performed.
3. Open the control access door.
4. Push in the gas control knob slightly and turn ⤵ clockwise to the "OFF" position. Do not force.
5. Close the control access door.

## - IPI LIGHTING INSTRUCTIONS -


### FOR YOUR SAFETY READ BEFORE LIGHTING

**WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.**

- A. This appliance is equipped with an ignition device which automatically lights the pilot. Do not try to light the pilot by hand.
- B. **BEFORE OPERATING** smell around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.
- WHAT TO DO IF YOU SMELL GAS
- Do not try to light any appliance.
  - Do not touch any electric switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.
  - C. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and replace any part of the control system and any gas control which has been under water.
  - D. If the gas valve requires repair, call a qualified service technician. Force or attempted repair may result in a fire or explosion.

## OPERATING INSTRUCTIONS

1. Stop! Read the safety information above on this label.
2. Read the owner's manual including the section on "Remote Control" operation if applicable.
3. Turn off all electric power to the appliance.
4. This appliance is equipped with an ignition device which automatically lights the pilot. Do not try to light the pilot by hand.
5. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, STOP! Follow "B" in the safety information above this label. If you do not smell gas, go to next step.
6. Turn on all electric power to the fireplace.
7. Turn "On" Switch that operates the Main Burner. For **Remote Control** units, press the ON/OFF key on the remote control. "ON" will be displayed on the LCD display and a "beep" will be heard at the unit to indicate the command has been received.
8. If the appliance will not operate, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.



## TO TURN OFF GAS TO APPLIANCE

1. Set thermostat to lowest setting. For **Remote Control** units, press the ON/OFF key on the remote control. "OFF" will be displayed on the LCD display and a "beep" will be heard at the unit to indicate the command has been received.
2. Turn off all electric power to the fireplace if service is to be performed.

## Troubleshooting the Gas Control System

### **WARNING**

**BEFORE DOING ANY GAS CONTROL SERVICE WORK, REMOVE THE GLASS FRONT.**

NOTE: Before troubleshooting the gas control system, be sure external gas shut off is in the "On" position.

| Problem   | Possible Causes  | Corrective Action   |
|---|--|---|
| Spark igniter will not light.   | Defective or misaligned electrode at pilot.<br>Defective igniter (push-button).  | Check for spark at electrode and pilot: if no spark and electrode wire is properly connected, replace igniter.<br>Using a match, light pilot. If pilot lights, turn off pilot and push the red button again. If pilot will not light - check gap at electrode and pilot should be 1/8" to 1/4" to have a strong spark.  |
| Pilot will not stay lit after carefully following lighting instructions.    | Defective thermocouple (flame switch where applicable).<br>Defective valve magnet.   | Check pilot flame. Must impinge on generator and thermocouple. Clean and/or adjust pilot for maximum flame impingement on generator and thermocouple. Replace thermocouple if pilot will not hold. (Hand tight 1/8 turn on replacement)<br>Replace valve, if pilot won't hold after the thermocouple is replaced.   |
| Pilot burning, no gas to burner, valve knob "ON", and wall switch "ON".     | Wall switch or wires defective.<br>Generator may not be generating sufficient voltage.<br>Plugged burner orifice.<br>Defective automatic valve operator. | Check wall switch and wires for proper connections. Jumper wire across terminals at wall switch. If burner comes on, replace defective wall switch. If okay, jumper wires, across wall switch wires at valve. If burner comes on, wires are faulty or connections are bad.<br>Check generator with millivolt meter. Take reading at generator terminals of gas valve. Should read 325 millivolts minimum while holding valve knob depressed in pilot position and wall switch "off" Replace faulty generator if reading is below specified minimum.<br>Check burner orifice for stoppage and remove.<br>Remove wall switch wires from gas valve. Install jumper wires from top bottom terminals of gas valve. Turn valve on "ON". If main burner does not light, replace valve. |
| Frequent pilot outage problem.  | Pilot flame may be too low or blowing (high) causing the pilot safety to drop out.   | Clean and/or adjust pilot flame for maximum flame impingement on generator and thermocouple.<br>*See NOTE below – Seven Day Timer   |
| Flame lifts off burner and goes out in less than 30 seconds.                | Inner 4" liner has come off flue or termination, flame is starving for oxygen.   | Attach 4" liner to flue or termination using screws, silicone and clamps as stated in manual.   |
| Flame lifts off burner on one side while the rest of the flame remains lit. | Improper installation of firebrick. Firebrick is likely leaning.   | Be sure to position firebrick against firebox walls and be sure to use brick clips attached to the inner side of firebox.   |

**\*NOTE:** The pilot system for this appliance may be equipped with a **Seven Day Timer**, in which case the pilot flame will be extinguished if the main burner has not been turned ON for seven days.

This Seven Day Cycle is reset every time the main burner is cycled ON / OFF and the pilot remains lit.

If more than seven days has passed since the main burner has been cycled ON / OFF and the pilot is also out, follow the procedures described in this manual to light the pilot.

**NOTE: MILLIVOLT UNITS WITH 7 DAY TIMER** – When lighting pilot, the Pilot Knob must be pressed until a **BEEP** is heard. This procedure may take up to **TWO MINUTES**.



## IPI PROFLAME 2 - COMPONENT PARTS

|  | PART NO.    | DESCRIPTION                                   |
|--|-------------|---|
| 1.   | 1005-P001SI | Valve IPI Proflame PF2 885.001 NG - Stepper   |
| 2.   | 1005-P002SI | Valve IPI Proflame PF2 885.002 LP - Stepper   |
| 3.   | 1005-P325SI | Module IPI - Proflame 2 - 584.325             |
| 4.   | 1005-P627SI | Module IPI – Proflame 2 - Basic - 584.627     |
| 5.   | 1005-P924SI | Harness PF2 - 584.924                         |
| 6.   | GTMFL       | Transmitter- PF2 - 584.090 - WiFi Version     |
| 6b.  | 1005-P042SI | Transmitter- PF2 - 584.042 - Non-WiFi Version |
| 6c.  | 1005-P080SI | Transmitter- PF2 - 584.080 - WiFi Version     |
| <b>For Replacement Transmitters, Replace with Same Part Number</b> |             |   |
| 7.   | 584-PWR-C   | Wire Harness PF2 – Power Cord                 |
| 8.   | 584-X4P     | Terminal Block                                |
| 9.   | 584-X10     | Wire Harness PF2                              |
| 10.  | 584-ACC01-C | Wire Harness PF2 - Fan/Light                  |
| 11.  | 584-X8-B    | Wire Harness PF2 - Optional Reset Harness     |
| 12.  | 584-X12     | Optional Power Vent Harness                   |


**6** Proflame Transmitter  
0.584.090 - WiFi  
Current Version



**6b** Proflame Transmitter  
0.584.042 - Non-WiFi




**6c** Proflame Transmitter  
0.584.080 - WiFi





## IPI - PF1 and PF2 Common Components

|     | PART NO.    | DESCRIPTION  |                          |
|-----|-------------|--|--------------------------|
| 13. | 1002-P033SI | TC - Pilot Burner IPI (Assembled) NG 199.033                         |                          |
| 14. | 1002-P047SI | TC - Pilot Burner IPI (Assembled) LP 199.047                         |                          |
| 15. | 1001-P166SI | TC - Orifice Pilot NG 977.166 #62 (IPI)                              |                          |
| 16. | 1001-P168SI | TC - Orifice Pilot LP 977.168 #35 (IPI)                              |                          |
| 17. | 1001-P280SI | TC - Tubing W/Fittings 1/8 2.182.280                                 |                          |
| 18. | 1002-P012SI | IPI Stepper Kit - LP 907.012   | <b>P2<br/>CONVERSION</b> |
| 19. | 1002-P013SI | IPI Stepper Kit - NG 907.013   |                          |
| 20. | 1002-P014SI | IPI Reg Kit - LP Hi-Lo 907.014                                       | <b>P1<br/>CONVERSION</b> |
| 21. | 1002-P016SI | IPI Reg Kit - NG Hi-Lo 907.016                                       |                          |
| 22. | 1002-P017SI | TC - Electrode Cable & Sparker IPI 915.017 24"                       |                          |
| 23. | 1002-P119SI | TC - Electrode Cable & Sparker IPI 35"<br>(Infinite, ZCVRB47, VRB46) |                          |
| 24. | 1002-P12BH  | IPI Battery Housing 12bh347-Gr                                       |                          |
| 25. | 1002-P903SI | TC - Electrode Flame Sense IPI 007.253/915.903<br>24"                |                          |
| 26. | 1002-P910SI | TC - Electrode Flame Sense 35"<br>(Infinite, ZCVRB47, VRB46)         |                          |

**NOTE:** Fan and / or Light Options are not available on some fireplaces. **Check with your dealer.**



Two Remote Control Models:



### Pairing Remote Control

- Install the 3 AAA batteries in the battery bay, located on the base of the Remote Control. Note polarity of the batteries and insert them as indicated.
- Connect the AC power supply to the IFC.
- **Press the Remote Pairing Button (SW1).** The IFC will “beep” and a red LED is illuminated on the Proflame 2 Module to indicate that the IFC is ready to synchronize with a Remote Control within 10 seconds. With the batteries already installed in the Remote Control, push the ON button. The receiver will “beep” four times to indicate the Remote Control's command is accepted.

The system is now initialized.

### Resetting Proflame 2 Module for Manual Use

Should the transmitter get misplaced, broken or not wanted the PF2 Module can be reset to a manual system. A manual on/off switch or thermostat may be installed at the X4 connector (this connection is Jumped at the factory) no power is required.

**Note: the fireplace accessories (fan, lights) will retain the last settings they had before being reset to manual mode.**

The following sequence must be followed to reset the PF2 Module:

- Press the **SW1** button until you hear three beeps.
- Within 10 seconds press the **SW1** button again until you hear it beep.
- The PF2 module may now be turned on/off manually (x4 connector) by a switch (not supplied), the pilot will remain on CPI (continuous pilot ignition) mode, all other functions of main burner, fan and lights will be on the high setting.

### Fan Startup and Shutdown Timings:

Fan setting is started with a delay of 5 minutes from the fireplace ignition and stopped with a delay of 12 minutes from the fireplace switching off.

### Low battery power detection

When the Remote Control's batteries are low, a Battery Icon will appear on the LCD display before all power is lost. When the batteries are replaced, this icon will disappear.


### Battery backup

The PF2 module is powered by line voltage (AC) with provision of battery backup in case of main power loss. Fans and lighting features will not function with the PF2 module is powered by battery backup. It is recommended that the 4 x AA batteries are changed before each heating season.



## Cold Climates – CPI Setting - Proflame 2 Remote Control

Use the CPI setting during cold weather, otherwise the fireplace may have a hard time starting up and establishing a flame. The **CPI** (Continuous Pilot Ignition) setting will keep the firebox and fireplace exhaust vent warm during cold weather. When the firebox and exhaust vent are warm, exhaust gasses will readily flow out of the firebox.




If the firebox and venting are too cold, there is resistance due to the heavy cushion of cold air, and combustion gasses may not rise into the exhaust vent, thus causing the fireplace to cycle or **Lockout** (if this happens see **Lockout Reset Procedures** below).


**NOTE:** The pilot system for this appliance may be equipped with a **Seven Day Timer**, in which case the pilot flame will be extinguished if the main burner has not been turned ON for seven days. This Seven Day Cycle is reset every time the main burner is cycled ON / OFF and the pilot remains lit. If more than seven days has passed since the main burner has been cycled ON / OFF and the pilot is also out, follow the procedures described in this manual to light the pilot.

### To switch from IPI to CPI Mode:

1. Turn the fireplace OFF using the **ON / OFF Key**.




2. Press the **Mode Key**. Display will appear as below.



3. Press UP on the **UP / DOWN Arrow Key**. Display will show **CPI**.

The module in the fireplace will beep once to confirm command.



### TO RETURN TO IPI (INTERMITTENT PILOT) MODE:

Repeat steps one and two, and then press DOWN on the **UP / DOWN Arrow Key**.

The module in the fireplace will beep once to confirm command.

## Lockout Reset Procedures – Proflame 2

If the fireplace has cycled too many times in a short period of time, it will shut down and become unresponsive to any new command.

The LED light on the Proflame 2 module in the fireplace will be flashing red.

This condition is a **Lockout** state.

### Lockout Reset Procedure:

1. Disconnect power from the Proflame 2 module in the fireplace for 10 seconds. This includes removing the backup batteries.
2. Once the 10 second interval has passed, reconnect power and reinstall backup batteries. The pilot should now try to light.
3. If the fireplace does not come on, call your fireplace technician.

## Proflame 2 Remote Control

### Remote-Flame Control

The proflame has six (6) flame levels. With the system on, and the flame level at the maximum in the appliance, pressing the Down Arrow Key once will reduce the flame height by one step until the flame is turned off.

The Up Arrow Key will increase the flame height each time it is pressed. If the Up Arrow Key is pressed while the system is on but the flame is off, the flame will come on in the high position. ( Fig. 7 & 8 ) A single "beep" will confirm reception of the command.





Fig. 7: Flame Off



Flame Level 1





Fig. 8: Flame level 5



Flame Level Maximum

### Room Thermostat ( Transmitter Operation)

The Remote Control can operate as a room thermostat. The thermostat can be set to a desired temperature to control the comfort level in a room.

To activate this function, press the Thermostat Key (Fig. 1). The LCD display on the Transmitter will change to show that the room thermostat is "ON" and the set temperature is now displayed (Fig. 9). To adjust the set temperature, press the Up or Down Arrow Keys until the desired set temperature is displayed on the LCD screen of the Transmitter.




Fig. 9

Fig. 10

## Smart Thermostat (Transmitter Operation)

The Smart Thermostat function adjusts the flame height in accordance to the difference between the set point temperature and the actual room temperatures. As the room temperature gets closer to the set point the Smart Function will modulate the flame down.

To activate this function, press the Thermostat Key (Fig. 1) until the word "SMART" appears to the right of the temperature bulb graphic (Fig. 11).

To adjust the set temperature, press the Up or Down Arrow Keys until the desired set temperature is displayed on the LCD screen of the Transmitter (Fig. 12).




Fig. 11: Smart flame function




Fig. 12

**Note:**  
When Smart Thermostat is activated, manual flame height adjustment is disabled.

## Fan Speed Control

If the appliance is equipped with a hot air circulating fan, the speed of the fan can be controlled by the Proflame system. The fan speed can be adjusted through six (6) speeds. To activate this function use the Mode Key (fig.1) to index to the fan control icon (Fig. 13). Use the Up/Down Arrow Keys (Fig.1) to turn on, off or adjust the fan speed (fig. 14). A single "beep" will confirm reception of the command.



Fig. 13




Fig. 14

## Remote dimmer control (Halogen lights only)

The auxiliary function controls the AUX power outlet by the dimmable light control. To activate this function use the Mode Key (fig. 1) to index to the AUX icon (fig. 15 & 16).

The intensity of the output can be adjusted through six (6) levels. Use the Up/Down Arrow Keys (Fig.1) adjust the output level (fig. 16). A single "beep" will confirm reception of the command.

**Note:**  
This function is only available in Room Thermostat or Smart Thermostat Control Mode.



Fig. 15






Fig. 16



**Manufactured by:** Kingsman Fireplaces  
**Fabrique par:** 2340 Logan Avenue  
Winnipeg, MB R2R 2V3

**For use with all Kingsman manufactured IP1 Profilame 2 models, for all types of gas noted on rating plate. Supply 120VAC 60Hz 3A, 6 volts battery backup.**

**Pour utilisation avec tous les modèles IP1 Profilame 2 fabriqués par Kingsman, pour tous les types de gaz noté sur la plaque signalétique. Voltage d'alimentation: 120VAC 60Hz 3A et 6 volts pour le bloc-piles de secours.**

**This component should be installed by a qualified service agency.**  
**Cette composante doit être installée par une entreprise de service qualifiée.**

Part #1005-P2SCH



## WMBH – Wall Mount Battery Holder – Proflame 1 and 2 IPI Models - Option


The WMBH provides the option for a more convenient and accessible location for the backup batteries.

**NOTE:** The WMBH is **NOT** a remote control receiver. It functions as a Battery Holder and mode selector switch **ONLY**.

**⚠ CAUTION- DO NOT PLUG THE ORIGINAL BATTERY HOLDER SUPPLIED WITH THE APPLIANCE INTO THE WMBH WIRING HARNESS. - NOT FOR USE WITH POWER VENTS -**


### Parts List:

- [1] Battery Holder
- [1] DCHS Mount Bracket
- [1] Wall Mount Cover Plate
- [1] 16 ft. Wiring Harness



### Installation:

- The Battery Holder can be mounted on a vertical wall stud using the DCHS as a mounting bracket.
- Ensure that the face is protruding 1/2" so that the face plate will be flush on the face of the wall.
- Drywall cutout size is 2" wide by 4-1/8" tall.
- Must be installed within 16ft of valve assembly (12ft recommended).



DCHS Mount Bracket




### Operating Instructions:



- **Proflame 1:** Set the switch on the Battery Holder to either the **ON** or **REMOTE** position. The WMBH functions as a battery backup should a power outage occur.
- **Proflame 2:** Set the switch on the Battery Holder to the **REMOTE** position. **NOTE:** If the switch on the Battery Holder is set to **ON**, the remote control will be disabled. The WMBH functions as a battery backup should a power outage occur. Refer to the manual that accompanies the Battery Holder for further instructions.

**Proflame 1:**  
-Plug **Battery Connector** into **Battery Holder** connection on wiring harness.

-The **Square Plug Connector** on the 16ft wiring harness is not used.



**Proflame 2:**  
-Plug the **Square Plug Connector** into the **User Interface Socket** in the P2 Module.  
-Plug the **Battery Connector** into **Battery Holder** connection on the Proflame 2 wiring harness.



White Square Connector

# IPI Electronic Ignition System

## Overview

The IPI system is an advanced burner controller that provides you with the option of having either a Standing-Pilot, or an intermittent igniting system. This alternating mode is controlled by the CPI/IPI Switch (Continuous Pilot Ignition/Intermittent Pilot Ignition) located on the IPI System Box. The difference between a Standing-Pilot and an Intermittent-Pilot is in whether the pilot stays lit or shuts off:

In Standing-Pilot, the pilot assembly is lit by the IPI Main Module and continues to stay lit until 1) the CPI/IPI Switch is switched to the IPI position; 2) a loss of electrical power (battery and AC source), 3) the flame sensor loses its signal, 4) the fuel supply discontinues, or 5) the IPI Main Module malfunctions.

In the Intermittent-Pilot mode, the pilot shuts off when the appliance is not in use. The advantage of this mode is that fuel is not consumed when the fireplace is not operating.

NOTE: In some jurisdictions Intermittent-Pilot is required. That means the pilot cannot remain lit when the appliance is not operating.

## Components

The core of the IPI system is the Main Module and the IPI Valve. With these two components the system is able to operate a gas fireplace. There are also other components available to complement the IPI system.

**IPI System Cover:** Is essential in keeping the components at their proper operating temperatures. **DO NOT OPERATE THE APPLIANCE WITHOUT THIS COVER.**

**Modulating Servo Motor:** Is an add-on valve component that permits HI/LO functionality to be controlled by the remote. Contrary to this feature is a Manual HI/LO Control Knob. The Modulating Servo Motor requires the Remote system to be present.

**Backup Battery Pack:** This component permits the IPI system to operate without the need for an external AC Adapter power source. The advantage to using the battery backup is that in the case of a power failure, the appliance is still operable.


**NOTE:** In certain instances the IPI Main Module requires resetting. This can occur if the system is unable to ignite the pilot or the main burner in the allotted time period. The IPI is programmed to lockout all commands. To reset this lockout you must deplete the system of all electrical power. This means to remove the batteries from the Battery Pack, remove the batteries from the Remote Receiver (if applicable), and disconnect the AC Adapter from the system. Leave the power off for approximately 25 seconds to clear its lockout.

**Remote Receiver:** This component provides the capability of controlling the appliance with a wireless remote transmitter.

### Standing Pilot Mode for Colder Climates (Below Freezing)

For IPI models it may be necessary to set the appliance to Standing Pilot mode to maintain heat in the cavity. The purpose of this procedure is to prevent cold air from penetrating the chimney and then onto the living space. Therefore, when the internal temperature is slightly elevated the fireplace is able to freely exhaust its combustion and hence making it easier to startup.


**NOTE:** The pilot system for this appliance may be equipped with a Seven Day Timer, in which case the pilot flame will be extinguished if the main burner has not been turned ON for seven days. This Seven Day Cycle is reset every time the main burner is cycled ON / OFF and the pilot remains lit. If more than seven days has passed since the main burner has been cycled ON / OFF and the pilot is also out, follow the procedures described in this manual to light the pilot.



## Proflame 1 -Remote Control Operation-

The Proflame GTM is configured to control the on/off main burner operation, its flame levels, and provides on/off and Smart \*thermostatic control of the appliance.

\*In the U.S.A. \*thermostats are not permitted for Vented Decorative Gas Fireplaces (ANSI Z21.50).



### Remote Receiver



### Transmitter

The Transmitter is powered by 3 AAA type batteries. A Mode Key is provided to Index between the features and a \*thermostat Key is used to turn on/off or index through \*thermostat functions

### Remote Receiver

The Receiver connects directly to the gas valve and stepper motor with a wiring harness. The Receiver is powered by 4 AA type batteries. The Receiver three position slider switch can be set to one of three positions: ON (Manual Override), Remote (Remote control) or Off.

### Initializing the System for the first time

Install 4 AA batteries into the receiver battery bay. Install 3 AAA type batteries in the Transmitter battery bay. Place the 3 position slider switch in the "Remote" position. Insert the end of a paper clip into the hole marked "PRG" on the Receiver front cover. The Receiver will "beep" three (3) times to indicate that it is ready to synchronize with a Transmitter. Push the On button. The Receiver will "beep" four times to indicate the Transmitter's command is accepted. The system is now initialized.

### Temperature indication Display


With the system in the "OFF" position, press the \*thermostat Key and the Mode Key at the same time. Look at the LCD screen on the Transmitter to verify that a C or F is visible to the right of the Room Temperature display.

### Turn the Appliance On or Off

Press the ON/OFF Key on the Transmitter

### Remote Flame Control

The Proflame GTM has six (6) flame levels. Pressing the Down Arrow Key once will reduce the flame height by one step until the flame is turned off. The Up Arrow Key will increase the flame height each time it is pressed. If the Up Arrow Key is pressed while the system is on but the flame is off, the flame will come on in the high position.



### Room \*thermostat ( Transmitter Operation)

The Remote Control can operate as a room \*thermostat. To activate this function, press the \*thermostat Key. The LCD display on the Transmitter will change to show that the room \*thermostat is "ON" and the set temperature is now displayed. To adjust the set temperature, press the Up or Down Arrow Keys until the desired set temperature is displayed on the LCD screen of the Transmitter.

### Smart \*thermostat (Transmitter Operation)

The Smart \*thermostat function adjusts the flame height in accordance to the difference between the set point temperature and the actual room temperatures. As the room temperature gets closer to the set point the Smart Function will modulate the flame down. To activate this function, press the \*thermostat Key until the word "SMART" appears to the right of the temperature bulb graphic. To adjust the set temperature, press the Up or Down arrow Keys until the desired set point temperature is displayed.

### Key Lock Function

This function will lock the keys to avoid unsupervised operation. To activate this function, press the MODE and the UP Arrow Key at the same time. To de-activate this function, press the MODE and the UP Arrow Key at the same time.

### Low Battery Detection

**Transmitter** - When the Transmitter batteries are low, a Battery Icon will appear on the LCD display of the Transmitter.

**Receiver** - When the Receiver batteries are low, No "beep" will be emitted from the Receiver when it receives an On/Off command from the Transmitter. When the batteries are replaced the "beep" will be emitted from the Receiver when the ON/OFF Key is pressed (See Initializing the System for the first time).

### Manual Bypass Of The Remote System

If the batteries of the Receiver or Transmitter are low or depleted, the appliance can be turned on manually by sliding the three position slider switch on the Receiver to the ON position. This will bypass the remote control feature and the appliance main burner will come on if the gas valve is in the "On" position.

### Wall Mount Option

**10ft. Extension Harness (Part No. 1001-P904SI) required.**

- The Remote Receiver can be mounted on a vertical wall stud using the DCHS as a mounting bracket.
- Ensure that the face is protruding 1/2" so that the face plate will be flush on the face of the wall.
- Drywall cutout size is 2" wide by 4-1/8" tall.
- Must be installed within 10ft of valve assembly (6ft recommended).


| PART NO.        | DESCRIPTION                             |
|-----------------|---|
| 1. 1006-P002SI  | Valve IPI Hi/Lo NG                      |
| 2. 1006-P003SI  | Valve IPI Hi/Lo LP                      |
| 3. 1002-P302SI  | IPI Ignition Board                      |
| 4. 1002-P047SI  | Pilot Assembly-LP -24" Wire             |
| 5. 1002-P033SI  | Pilot Assembly-NG -24" Wire             |
| 6. 1002-P850SI  | AC Wall Adapter                         |
| 7. 1002-P12BH   | Battery Pack                            |
| 8. 1001-P280SI  | TC - Tubing W/Fittings 1/8 2.182.280    |
| 9. 1001-P166SI  | TC - Orifice Pilot NG 977.166 #62 (IPI) |
| 10. 1001-P168SI | TC - Orifice Pilot LP 977.168 #35 (IPI) |

|                 |   |
|-----------------|---|
| 11. 1002-P012SI | IPI Stepper Kit - LP 907.012                                      |
| 12. 1002-P013SI | IPI Stepper Kit - NG 907.013                                      |
| 13. 1002-P014SI | IPI Reg Kit - LP Hi-Lo 907.014                                    |
| 14. 1002-P016SI | IPI Reg Kit - NG Hi-Lo 907.016                                    |
| 15. 1002-P017SI | TC - Electrode Cable & Sparker IPI 915.017 24"                    |
| 16. 1002-P119SI | TC - Electrode Cable & Sparker IPI 35" (Infinite, ZCVRB47, VRB46) |
| 17. 1002-P903SI | TC - Electrode Flame Sense IPI 007.253/915.903 24"                |
| 18. 1002-P910SI | TC - Electrode Flame Sense 35" (Infinite, ZCVRB47, VRB46)         |




**Proflame Transmitter**  
**1001-P023SI**


**NOTE:** Fan and / or Light Options are not available on some fireplaces.  
**Check with your dealer.**







Configuration #1: Basic manual HI/LO and manual ON/OFF capabilities.



**OPTIONAL:** For units with remote HI/LO capabilities, a modulating servo is required to be installed on the valve. The connectors to this servo must be connected to the Remote Harness as shown.



**NOTE:** Fan Option is not available on some models of fireplace. **Check with your dealer.**




## Operating the Receiver Without Batteries for GT / EGT / GTM / EGTM Remote Controls

-Wiring Harness P/N 1002-P906si required for both IPI & Millivolt systems.


-Millivolt Systems will also require Power Adapter P/N 1002-P850si.

The Remote Receiver & IPI or Millivolt system can be powered by the AC Adapter. This is advantageous if you do not want to use batteries. Simply connect the AC Adapter into the Remote Control Wiring Harness as per the diagrams below.

### IPI System EGTM



### Millivolt System GTM




# Proflame 1- Configuration #3: Remote ON/OFF, variable HI/LO, and fan capabilities

Refer to the fan installation/removal section for fan installation.


## SCHEMATIC

**NOTE:** This Configuration is not available on all models of fireplace. **Check with your dealer.**



## PICTURE


Note: If remote Control is used the battery Pack 1002-P12BH does not need to be used.



**NOTE:** Fan Option is not available on some models of fireplace. **Check with your dealer.**

# Vent Terminal Clearances

**NOTE:** A HORIZONTAL VENT CERTIFIED GUARD (SAFETY CAGE) IS AVAILABLE WHEN REQUIRED BY LOCAL CODES.



|          |  | Canadian installations <sup>1</sup>   | US installations <sup>2</sup>  |
|----------|--|---|--|
| <b>A</b> | Clearance above grade, veranda, porch, deck, or balcony  | 12 in (30 cm)   | 12 in (30 cm)  |
| <b>B</b> | Clearance to window or door that may be opened   | 6 in (15 cm) for appliances ≤ 10,000 Btu/h (3 kW), 12 in (30 cm) for appliances > 10,000 Btu/h (3 kW) and ≤ 100,000 Btu/h (30 kW), 36 in (91 cm) for appliances > 100,000 Btu/h (30 kW) | 6 in (15 cm) for appliances ≤ 10,000 Btu/h (3 kW), 9 in (23 cm) for appliances > 10,000 Btu/h (3 kW) and ≤ 50,000 Btu/h (15 kW), 12 in (30 cm) for appliances > 50,000 Btu/h (15 kW) |
| <b>C</b> | Clearance to permanently closed window   | 12 inches (30cm) recommended to prevent condensation on window  | 12 inches (30cm). 9 inches (23cm) for appliances 50,000 Btu's and lower  |
| <b>D</b> | Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61 cm) from the center line of the terminal | 18 inches (46cm)  | 18 inches (46cm)   |
| <b>E</b> | Clearance to unventilated soffit   | 12 inches (30cm)  | 12 inches (30cm)   |
| <b>F</b> | Clearance to outside corner  | 3" *  | 3" *   |
| <b>G</b> | Clearance to inside corner   | 3" *  | 3" *   |
| <b>H</b> | Clearance to each side of center line extended above meter/regulator assembly  | 3 ft (91 cm) within a height 15 ft (4.5 m) above the meter/regulator assembly   | 3 ft (91 cm) within a height 15 ft (4.5 m) above the meter/regulator assembly  |
| <b>I</b> | Clearance to service regulator vent outlet   | 3 ft (91 cm)  | 3 ft (91 cm)*  |
| <b>J</b> | Clearance to non-mechanical air supply inlet to building or the combustion air inlet to any other appliance  | 6 in (15 cm) for appliances ≤ 10,000 Btu/h (3 kW), 12 in (30 cm) for appliances > 10,000 Btu/h (3 kW) and ≤ 100,000 Btu/h (30 kW), 36 in (91 cm) for appliances > 100,000 Btu/h (30 kW) | 6 in (15 cm) for appliances ≤ 10,000 Btu/h (3 kW), 9 in (23 cm) for appliances > 10,000 Btu/h (3 kW) and ≤ 50,000 Btu/h (15 kW), 12 in (30 cm) for appliances > 50,000 Btu/h (15 kW) |
| <b>K</b> | Clearance to a mechanical air supply inlet   | 6 ft (1.83 m)   | 3 ft (91 cm) above if within 10 ft (3 m) horizontally  |
| <b>L</b> | Clearance above paved sidewalk or paved driveway located on public property  | 7 ft (2.13 m)   | *(Notes: 2)  |
| <b>M</b> | Clearance under veranda, porch, deck, or balcony   | 12 in (30 cm)‡  | 12 in (30 cm) *  |
| <b>N</b> | Where a vent termination may cause hazardous frost or ice accumulations on adjacent property surfaces  | ** (Notes: 1)   | *(Notes: 2)  |
| <b>O</b> | Clearance above highest point of exit on roof  | 18 in (45cm)  | 18 in (45cm)   |
| <b>P</b> | Clearance to perpendicular or adjacent wall  | 24 in (60cm)  | 24 in (60cm)   |

## Notes:

1) In accordance with the current CSA B149.1, Natural Gas and Propane Installation Code.

2) In accordance with the current ANSI Z223.1/NFPA 54, National Fuel Gas Code.

\* Clearance in accordance with local installation codes and the requirements of the gas supplier.

\*\* A vent shall not terminate directly above a paved sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings. Note: This does not apply to non-condensing appliances (Province of Ontario ONLY).

‡ Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.

It is imperative that the vent termination be located observing the minimum clearances as shown. There must not be any obstruction such as bushes, garden sheds, fences, decks or utility buildings within 24" from the front of the termination plate.

Do not locate termination where excessive snow or ice build-up may occur. Be sure to check vent termination area after snow falls and clear to prevent accidental blockage of venting system. When using snow blowers, make sure snow is not directed towards vent termination area. Venting terminal shall not be recessed into a wall or siding. If finishing the outside wall with vinyl or wood siding it is **required** that a Siding Shield be installed, Part Number ZDVSSLR.



# General Vent Installation Information

**⚠ WARNING:** DO NOT mix parts from different systems unless stated in the manual.

This gas appliance is approved to be vented either through the side wall or vertically through the roof. Only Kingsman Flex (Z-Flex) Venting Kits and components specifically approved and LABELED for this appliance may be used. This appliance is also approved for use with MG-DuraVent Direct Vent system (DirectVent Pro and DirectVent Pro Concentric Flex), BDM Pro Form Direct Vent, Ameri-Vent Direct Vent Pipe System, ICC Excel Direct, Metal Fab Sure-Seal DV and Selkirk Direct Temp.

## Rigid or Hard Pipe


When using MG DuraVent, Ameri-Vent pipe, BDM Pro Form Direct Vent, ICC Excel Direct, Metal Fab Sure-Seal DV and or Selkirk Direct Temp a DuraVent hard pipe adapter must be used (part # ZDVDFa for fireplaces, and part # ZDVdKA for Stoves and Serene Series). Follow installation instructions provided by MG DuraVent/Ameri-Vent/Selkirk Direct Temp, ICC Excel Direct, and Metal Fab Sure-Seal DV for installation of pipe and adhere to the clearance to combustibles provided in this manual.

**Apply a bead of Mill Pac high temp sealant at the flue of the appliance when using a DuraVent adapter.**

**NOTE:** It is critical to the proper and safe operation of this fireplace that on all connections the inner liner and the outer casing are both caulked with liberal amounts of sealant. Do not use any kind of tape or silicone other than that recommended in this manual. Use Mill Pac Sealant.

**NOTE:** These actions are essential for proper resealing or reinstallation of the vent-air intake system.

**REMEMBER THAT A 1/4" VERTICAL RISE IS REQUIRED FOR EVERY 12" OF HORIZONTAL RUN.**



## Flex Pipe Venting

Kingsman Flex pipe is shipped in unexpanded length. When installing pipe expand the lengths. Pipe can be expanded to twice their lengths e.g., 4ft. to 8ft. Fully expand pipe and cut off excess. Do not use more than 2 couplers to extend short pipes. Single sections are preferred in an installation attaching at the fireplace and termination.

Place the spring spaces provided approximately every two feet to stabilize 4" flex in the center of 7" flex. When forming bends place spring in bend or before and after. (See Fig. 1). Horizontal runs require support metal straps every 2 feet. In offset installation support straps should be used to stabilize pipe.

Expand 4" and 7" flex pipe to the point that the 7" protrudes approximately 2 to 3 inches past outer wall and the 4" flex protrudes approximately 2 to 3 inches past the 7" flex. (See Fig. 1). Attach the 4" pipe to the termination first and secure with sealant and screws then attach the 7" flex to the termination with caulking and screws. Termination may then be moved back to the outer wall and attached to home screwing into the framing. Silicone around termination to waterproof. If siding shield is going to be used attach this using same attaching hole as the top of termination after termination has been caulked for water proofing.


## Use Hi Temp Sealant

Apply a bead of Mill Pac high temp sealant to all joints and use four screws to secure each pipe at fireplace, termination and any joint if joining any sections of pipe.


## Preventing Moisture Problems

Insulate wall thimbles and attic insulation shields for vertical attic terminations with non-combustible mineral wool Insulation (Roxul, Rockwool, Thermafiber UltraBatt, etc.). Attach and seal the outer perimeter of the wall thimble or attic insulation shield to the existing vapor barrier.

### FDVHT Termination




### FDVHSQ Termination




Since it is very important that the vent system maintain its balance between the combustion air intake and the flue gas exhaust, certain limitations as to vent configurations apply and must be adhered to.

See venting chart for total horizontal and vertical runs.


- For every 90° elbow after the first 90° elbow the horizontal run must be reduced by 36".
- For every 45° elbow after the first 90° elbow the horizontal run must be reduced by 18".
- This does not apply if the 45° elbows are installed on the vertical part of the vent system. 45° elbows can be installed in either the horizontal or vertical runs.



The minimum allowable configuration is 4-1/2 feet vertical with unit 4" from wall.



The maximum horizontal vent run with one 90° elbow attached is 20 feet with 7 feet vertical.



The maximum vertical rise is 40 feet.

**Minimum clearances on venting (4" to top of elbow), (2-1/2" from top of horizontal pipes), (1" on all other existing pipes).**

Only trim kit(s) supplied by the manufacturer shall be used in the installation of this appliance. Draft Relief Openings must not be covered or blocked.



**IMPORTANT:** Always locate the fireplace in such a way that a minimum of offsets and/or horizontal runs are required. 1/4" vertical rise is required for every 12" horizontal run.

**IMPORTANT: ALWAYS LOCATE THE STOVE IN SUCH A WAY AS TO MINIMIZE THE NUMBER OF OFFSETS AND/OR HORIZONTAL RUNS. A 1/4" VERTICAL RISE IS REQUIRED FOR EVERY 12" OF HORIZONTAL RUN.**

The following table shows the relationship between vertical and horizontal vent lengths and will help you to determine the correct vent lengths for optimum stove performance.

**How to use the Vent Table:**

1. Determine the height of the system and the number of elbows required.
2. Use the Venting Chart to determine the maximum horizontal distance allowed.



| Total Vertical |        | Max. Total Horizontal |        |
|----------------|--------|-----------------------|--------|
| Feet           | Meters | Feet                  | Meters |
| 4½             | 1.4    | 3                     | 0.9    |
| 5              | 1.5    | 4                     | 1.2    |
| 6              | 1.8    | 8                     | 2.4    |
| 7              | 2.1    | 20                    | 6.1    |
| 8              | 2.4    | 20                    | 6.1    |
| 9              | 2.7    | 20                    | 6.1    |
| 10             | 3.0    | 20                    | 6.1    |
| 11             | 3.4    | 20                    | 6.1    |
| 12             | 3.7    | 20                    | 6.1    |
| 13             | 4.0    | 20                    | 6.1    |
| 14             | 4.3    | 20                    | 6.1    |
| 15             | 4.6    | 20                    | 6.1    |
| 16             | 4.9    | 20                    | 6.1    |
| 17             | 5.2    | 20                    | 6.1    |
| 18             | 5.5    | 20                    | 6.1    |
| 19             | 5.8    | 20                    | 6.1    |
| 20             | 6.1    | 20                    | 6.1    |
| 25             | 7.5    | 15                    | 4.6    |
| 30             | 9.0    | 10                    | 3.0    |
| 40             | 12     | 0                     | 0      |

**Note:** For each 45° elbow installed in the horizontal run, the length of the horizontal run must be reduced by 18" (45 cm). This does not apply if the 45° elbows are installed on the vertical part of the vent system.

**Note:** For each additional 90° elbow installed in the horizontal run, the length must be reduced by 36" (90 cm). Maximum number of 90° elbows are three per installation.




FIGURE 1




FIGURE 2

1. Use the Venting Table to determine the minimum distance from the bottom of fireplace to center of vent. Cut a hole through the wall allowing for an 11" x 11" (inside diameter) in combustible walls for wall thimble or an 8" diameter hole in a non-combustible wall (See Figure 3).
2. For the clearance to combustibles above a 90 degree bend see **Clearance to Combustibles** section.
3. Select the approximate vent length, precise measurements are not needed as your flex pipe can be expanded to twice its shipped length for ease of installation
4. To install wall thimble center over 11" x 11" (inch) framing from both sides of wall and secure. Route flex vent pipe through wall thimble.

**WARNING: A HORIZONTAL VENT CERTIFIED GUARD (SAFETY CAGE) IS AVAILABLE WHEN REQUIRED BY LOCAL CODES.**




FIGURE 3


5. Before joining pipes, apply a bead of high temperature sealant (Mill Pac) to end of pipe. First attach the four inch (4") flue pipe to the vent termination with sealant, and secure with the four screws provided. At this time make sure the spacer springs are attached to the (4") flex pipe as required. Then attach the seven inch (7") pipe by the same method.
6. Mount vent termination and seal to wall using caulking around the wall thimble to weather proof. After installing the vent termination, double check to make sure the pipe extends properly through wall thimble and into vent termination.
7. Before joining pipes to fireplace flue, apply a bead of high temperature sealant (Mill Pac) to end of pipe. First attach the four inch (4") flue pipe to fireplace with sealant, and secure with the four screws provided. At this time verify that the spacer springs are attached properly to the (4") flex pipe as required. Then attach the seven inch (7") pipe by the same method.
8. Support horizontal pipes every two (2) feet (61 cm) with metal strap bands. Re-check fireplace to make sure it is levelled and properly positioned and secured.
9. Support vertical pipes to maintain a minimum of 1" or greater clearance to combustibles with metal strapping bands.

If finishing the outside wall with vinyl or wood siding it is **required** that a Siding Shield be installed, Part Number ZDVSSLR.

Two snorkel terminations are available if a vertical rise is necessary on the exterior side of a building:


**Z47ST24** (24" Tall, 14-1/2" Center to Center)      **Z47ST36** (36" Tall, 26-1/2" Center to Center)

Follow standard horizontal venting installation procedures. If the Snorkel Termination is to be located below grade, a window well is recommended with adequate and proper drainage as per local codes. Leave 2" clearance below snorkel to prevent water from entering the Snorkel Termination. Do not enclose the Snorkel within a wall or other type of enclosure and **do not back fill**. Ensure that grade level slopes away from the building. Follow all local codes.



**-FOLLOW ALL LOCAL CODES-**

- A safety cage (Z57STSC) is also available. Place safety cage over snorkel and mount with [4] DT screws (supplied with safety cage).






## VERTICAL VENTING OVER 15 FEET

The Air Intake Plate must be adjusted down to the lowest position when venting over 15 ft. vertical.


### 15' OR OVER VERTICAL VENTING AIR INTAKE PLATE ADJUSTMENT



**NOTE:** Unit comes preset for vertical venting under 15 feet.

Follow these instructions when venting exceeds 15 feet vertical.

1. Locate the 3 x 1/4" hex screws and, using a nut driver, loosen the screws 1 turn.
2. Lower the Air Adjustment Plate as shown in the diagram. (Full Down Position)
3. Tighten the 3 x 1/4" hex screws.



### Using Flex Bends

Use roof support and rigid pipe at roof level. Flex pipe is not permitted within roof support.

When penetrating the roof a rigid galvanized pipe must be used. Attach flex pipe to the rigid pipe with high temperature sealant, secure with four screws assuring the flex pipe and rigid pipe are secured. Attach rigid pipe to termination with sealant and screw with 4 sheet metal screws. The Inner flex pipe must be secured with 4 screws which must penetrate both the flex pipe and inner section of termination. Attach 7" rigid pipe to 7" termination with sealant and screw with 4 sheet metal screws.

Vertical termination clearance is 18" [45.7cm] above the roof, measured from highest point of exit on the roof line.

Support vertical pipes to maintain minimum of one inch or greater clearances to combustibles.

### Roof Flashing


Ensure that you have the proper roof flashing by checking your roof pitch using a level and two rulers, or by using a roof pitch card.


Slide a Roof Flashing suitable to your roof slope over the vent. Place the edge of the flashing plate that will be on the higher part of the roof slope under the shingles. Both the sides and the lower edge lay on top of the shingles.

**NOTE: At the top edge of the flashing plate, lift the shingles and nail the plate to the roof deck, then cement the shingles to the plate with a suitable waterproof mastic.**

Ensure that the chimney is plumb. Square up the flashing plate and nail in place to the roof deck. Use 12 nails with neoprene washers or cover the heads with a suitable waterproof mastic. Wrap the storm collar around the vent above the flashing. Secure the ends together loosely with nut and bolt supplied. Slide the collar down the vent until it comes in contact with the flashing. Tighten the bolt and seal the Storm Collar to the vent with a suitable waterproof non-combustible mastic.

The flashing and storm collar should be painted to match the roof shingles. This will extend its life and improve the appearance. Clean, prime and paint with suitable painting products.





### Vertical Venting in Cold Climates

In cold climate conditions where temperatures go below -10°C [14°F], we recommend that the chase be insulated and where the vent pipe enters into the attic space that the pipe be wrapped with an insulated Mylar sleeve. This will increase the temperature of the vent and help the appliance to vent properly in cold weather conditions.

It is also important in vertical vented direct vent appliances that the appliance be operated daily during the winter months as this will help stop the Termination from freezing up. We recommend using a thermostat set at room temperature to allow the unit to cycle. For IPI models it may be necessary to set the appliance to Standing Pilot mode to maintain heat in the cavity. The purpose of this procedure is to prevent cold air from penetrating the chimney and then onto the living space. Therefore, when the internal temperature is slightly elevated the fireplace is able to freely exhaust its combustion and hence making it easier to startup.

Listed for USA/Canada as a Vented Gas Fireplace Heater, Dual Burner, Ceramic Glass, Glowing Embers, 4/7" Flue 28,500 BTU NG, 26,000 BTU Propane

### Fireplace Part Numbers

|             |   |
|-------------|---|
| FDV200SN    | Free Standing Direct Vent Stove, Millivolt - Natural Gas                      |
| FDV200SNE   | Free Standing Direct Vent Stove, Proflame 1 IPI - Natural Gas                 |
| FDV200SNE2  | Free Standing Direct Vent Stove, Remote Control, Proflame 2 IPI - Natural Gas |
| FDV200SLP   | Free Standing Direct Vent Stove, Millivolt - Propane                          |
| FDV200SLPE  | Free Standing Direct Vent Stove, Proflame 1 IPI - Propane                     |
| FDV200SLPE2 | Free Standing Direct Vent Stove, Remote Control, Proflame 2 IPI - Propane     |

### LOG SET: (REQUIRED FOR EACH UNIT)

|         |                                      |
|---------|--------------------------------------|
| LOGC200 | Log Set - Cast Split Oak with Embers |
| LOGF200 | Log Set - Fiber, 5 pieces            |

### REMOTE CONTROL - MILLIVOLT

|        |   |
|--------|---|
| GFRC   | Remote Control Millivolt / IPI - On/Off               |
| GTRC   | Remote Control Millivolt - Thermostat                 |
| GTMRCN | Remote Control Millivolt - Thermostat/Modulating - NG |
| GTMRCP | Remote Control Millivolt - Thermostat/Modulating - LP |

### ACCESSORIES

|          |  |
|----------|--|
| F7DBC    | Decorative Black Collar 7"                                     |
| F45FK    | Fan Kit w/Variable Speed Control (Temperature Sensing)         |
| F45FK2   | Fan Kit - Proflame 2 Units                                     |
| FDV200RL | Refractory Liner   |
| Z2MT     | Thermostat Millivolt Wall Mount                                |
| Z80PT    | Thermostat Programmable Digital Millivolt Wall Mount (1F80-40) |
| F7DTP    | Decorative Black Wall Trim Plate                               |
| OFP42SA  | Spark Assist   |
| F200CSS  | Safety Screen Replacement                                      |

### VALVE SYSTEM PARTS / MILLIVOLT

|             |                                  |
|-------------|----------------------------------|
| 1000-P136WR | Generator / Thermopile           |
| 1001-P069SI | Electrode Sparker 915.069 TC SIT |
| 1001-P216SI | Thermocouple 290.216 TC SIT      |
| 1001-P165SI | Orifice Pilot NG 977.165 TC SIT  |
| 1001-P167SI | Orifice Pilot LP 977.167 TC SIT  |
| 1001-P280SI | Tubing 24"                       |
| 1001-P633SI | Valve Nova LP Hi/Lo 0820651      |
| 1001-P634SI | Valve Nova NG Hi/Lo 0820652      |
| 1001-P713SI | Pilot Burner LP 199.713 TC SIT   |
| 1001-P714SI | Pilot Burner NG 199.714 TC SIT   |

|             |  |
|-------------|--|
| 1000-214    | #Piezo-Igniter 1244-17 Mark21            |
| 1001-P144SI | Nut- Electrode Universal Bushing 974 144 |

### IPI PROFLAME 1 - COMPONENT PARTS

|             |  |
|-------------|--|
| 1006-P002SI | Valve IPI Proflame PF1 886.002 NG - HI/LO  |
| 1006-P003SI | Valve IPI Proflame PF1 886.003 LP - HI/LO  |
| 1002-P322SI | IPI Module PF1 - 584.322                   |
| 1002-P850SI | IPI Power Adapter IPI - 584.850 AC         |
| 1002-P905SI | IPI Wire Harness for EGT Remotes - 584.905 |
| 1002-P912SI | IPI Wire Harness for Module - 584.912      |

### IPI PROFLAME 2 - COMPONENT PARTS

|             |   |
|-------------|---|
| 1005-P001SI | Valve IPI Proflame PF2 885.001 NG - Stepper |
| 1005-P002SI | Valve IPI Proflame PF2 885.002 LP - Stepper |
| 1005-P325SI | Module IPI - Proflame 2 - 584.325           |
| 1005-P924SI | Harness PF2 - 584.924                       |
| 1005-P042SI | Transmitter - PF2 - Black 584.042           |
| 584-PWR-C   | Wire Harness PF2                            |
| 584-X4P     | Terminal Block                              |
| 584-X10     | Wire Harness PF2                            |
| 584-ACC01-C | Wire Harness PF2 - Fan/Light                |
| 584-X8-B    | Wire Harness PF2 - Optional Reset Harness   |

### IPI PROFLAME 1 AND PROFLAME 2 COMMON COMPONENTS

|             |  |
|-------------|--|
| 1002-P033SI | TC - Pilot Burner IPI (Assembled) NG 199.033       |
| 1002-P047SI | TC - Pilot Burner IPI (Assembled) LP 199.047       |
| 1001-P166SI | TC - Orifice Pilot NG 977.166                      |
| 1001-P168SI | TC - Orifice Pilot LP 977.168                      |
| 1001-P280SI | TC - Tubing c/w Fittings 1/8 2.182.280             |
| 1002-P012SI | IPI Stepper Kit - LP 907.012                       |
| 1002-P013SI | IPI Stepper Kit - NG 907.013                       |
| 1002-P014SI | IPI Regulator Kit - LP HI-LO 907.014               |
| 1002-P016SI | IPI Regulator Kit - NG HI-LO 907.016               |
| 1002-P017SI | TC - Electrode Cable & Sparker IPI 915.017 24"     |
| 1002-P119SI | TC - Electrode Cable & Sparker IPI (Infinite) 35"  |
| 1002-P12BH  | IPI Battery Housing 12BH347-GR                     |
| 1002-P903SI | TC - Electrode Flame Sense IPI 007.253/915.903 24" |
| 1002-P910SI | TC - Electrode Flame Sense IPI (Infinite) 35"      |

|             |                        |
|-------------|------------------------|
| 1002-P089SI | Spark Electrode (Long) |
|-------------|------------------------|

|             |                               |
|-------------|-------------------------------|
| 1002-P113SI | Electrode Flame Sensor (Long) |
|-------------|-------------------------------|

### CONVERSION KIT

|            |   |
|------------|---|
| 200DV-CKLP | Conversion Kit - Millivolt - To Propane – FDV200SLP |
|------------|---|

|            |  |
|------------|--|
| 200DV-CKNG | Conversion Kit - Millivolt - To Natural Gas - FDV200SN |
|------------|--|

|             |   |
|-------------|---|
| 200DV-CKLPI | Conversion Kit - Proflame 1 - To Propane – FDV200SLPE |
|-------------|---|

|             |  |
|-------------|--|
| 200DV-CKNGI | Conversion Kit - Proflame 1 - To Natural Gas – FDV200SNE |
|-------------|--|

|             |  |
|-------------|--|
| 200DV-CKLP2 | Conversion Kit - Proflame 2 - To Propane – FDV200SLPE2 |
|-------------|--|

|             |   |
|-------------|---|
| 200DV-CKNG2 | Conversion Kit - Proflame 2 - To Natural Gas – FDV200SNE2 |
|-------------|---|

### REPLACEMENT BURNER ASSEMBLY

|            |   |
|------------|---|
| 200S-BLPSI | Burner Assembly- Propane c/w Valve System - Millivolt |
|------------|---|

|            |   |
|------------|---|
| 200S-BNGSI | Burner Assembly- Natural Gas c/w Valve System - Millivolt |
|------------|---|

|             |  |
|-------------|--|
| 200S-BLPSIE | Burner Assembly- Propane c/w Valve System – Proflame 1 |
|-------------|--|

|             |  |
|-------------|--|
| 200S-BNGSIE | Burner Assembly- Natural Gas c/w Valve System – Proflame 1 |
|-------------|--|

|             |  |
|-------------|--|
| 200S-BLPSI2 | Burner Assembly- Propane c/w Valve System – Proflame 2 |
|-------------|--|

|             |  |
|-------------|--|
| 200S-BNGSI2 | Burner Assembly- Natural Gas c/w Valve System – Proflame 2 |
|-------------|--|

### MISCELLANEOUS PARTS

|            |                            |
|------------|----------------------------|
| 1000-150GE | Silicone GE Red IS806 #736 |
|------------|----------------------------|

|            |                                |
|------------|--------------------------------|
| 1000-150MP | Hi-Temp Millpac Sealant 840099 |
|------------|--------------------------------|

|          |                               |
|----------|-------------------------------|
| 1000-214 | Piezo-Igniter 1244-17 MARK 21 |
|----------|-------------------------------|

|          |                                   |
|----------|-----------------------------------|
| 1000-215 | Pal Nut (18MMX1.5MM)BLK (1364.03) |
|----------|-----------------------------------|

|          |               |
|----------|---------------|
| 1000-216 | On/Off Switch |
|----------|---------------|

|          |                              |
|----------|------------------------------|
| 1000-255 | Orifice Brass - (State Size) |
|----------|------------------------------|

|          |  |
|----------|--|
| 2000-080 | Thermodisc 2450 (For Blower) - Millivolt |
|----------|--|

|          |                         |
|----------|-------------------------|
| 2000-081 | Blower motor QLN65/2400 |
|----------|-------------------------|

|          |  |
|----------|--|
| 1000-306 | Thermalcord - Adhesive Back for Door Frame |
|----------|--|

|          |  |
|----------|--|
| 1000-085 | Control Variable Speed KBWC-13BV - Millivolt |
|----------|--|

|        |                               |
|--------|-------------------------------|
| FP15GC | Stainless Steel Gas Connector |
|--------|-------------------------------|

|          |             |
|----------|-------------|
| 6000-130 | Relief Felt |
|----------|-------------|

|         |                                     |
|---------|-------------------------------------|
| 200-310 | Ceramic Glass Front c/w Thermalcord |
|---------|-------------------------------------|

|           |        |
|-----------|--------|
| 350-EMBER | Embers |
|-----------|--------|

|             |  |
|-------------|--|
| 350- P217SI | Knob Extension 1-1/2" – ON/OFF - Millivolt |
|-------------|--|

|            |   |
|------------|---|
| 350-P218SI | Knob Extension 1-1/2" HI/LO - Millivolt |
|------------|---|

### KINGSMAN FIREPLACE VENTING

|        |   |
|--------|---|
| FDVHSK | <b>Horizontal Vent Starter Kit - (Direct Vent Stoves)</b> Starter Kit Contains:<br>Horizontal Vent Termination, Zero Clearance Wall Sleeve, Black Wall Trim |
|--------|---|

Ring, 7" Dia. Black Pipe 24" Length, 7" Dia. Black Pipe 48"Length 7" - 90 Degree Black Elbow, 4" Flex 48" Unexpanded (96" Expanded) 7" Black Bands(3), Mill Pac.

|        |   |
|--------|---|
| FDVVSK | <b>Vertical Vent Starter Kit - (Direct Vent Stoves)</b> Starter Kit Contains: |
|--------|---|

Attic Insulation Shield, Fire Stop, Ceiling Trim Plate, Black Trim Ring (2), Roof Support, Spacer Springs(6), Mill Pac

|       |                           |
|-------|---------------------------|
| Z47VT | Vertical Vent Termination |
|-------|---------------------------|

|         |   |
|---------|---|
| FDVVT40 | Vertical Vent Termination Converts from 15' -40' to 15' and under |
|---------|---|

|       |                             |
|-------|-----------------------------|
| FDVHT | Horizontal Vent Termination |
|-------|-----------------------------|

|         |  |
|---------|--|
| FDVHSCU | Safety Cage for Horizontal Termination |
|---------|--|

|        |                               |
|--------|-------------------------------|
| FDVHSQ | Horizontal Square Termination |
|--------|-------------------------------|

|         |   |
|---------|---|
| Z47ST24 | Horizontal Snorkel Termination (24" Tall, 14-1/2" Center to Center) |
|---------|---|

|         |   |
|---------|---|
| Z47ST36 | Horizontal Snorkel Termination (36" Tall, 26-1/2" Center to Center) |
|---------|---|

|         |  |
|---------|--|
| Z57STSC | Safety Cage for Horizontal Snorkel Termination |
|---------|--|

|        |                                |
|--------|--------------------------------|
| FDV48P | Black Pipe (7" Diameter x 48") |
|--------|--------------------------------|

|        |                                |
|--------|--------------------------------|
| FDV36P | Black Pipe (7" Diameter x 36") |
|--------|--------------------------------|

|        |                                |
|--------|--------------------------------|
| FDV24P | Black Pipe (7" Diameter x 24") |
|--------|--------------------------------|

|        |                                |
|--------|--------------------------------|
| FDV12P | Black Pipe (7" Diameter x 12") |
|--------|--------------------------------|

|        |                                       |
|--------|---------------------------------------|
| FDVE90 | Black Elbow (7" Diameter x 90 Degree) |
|--------|---------------------------------------|

|        |                                       |
|--------|---------------------------------------|
| FDVE45 | Black Elbow (7" Diameter x 45 Degree) |
|--------|---------------------------------------|

|        |   |
|--------|---|
| ZDVKDA | Dura-Vent Stove Adapter ( for Direct Vent Stoves) |
|--------|---|

|        |                         |
|--------|-------------------------|
| ZDVAIS | Attic Insulation Shield |
|--------|-------------------------|

|          |                             |
|----------|-----------------------------|
| ZDVAIS24 | Attic Insulation Shield 24" |
|----------|-----------------------------|

|        |                |
|--------|----------------|
| ZDVVOS | Offset Support |
|--------|----------------|

|       |                 |
|-------|-----------------|
| ZDVFS | Firestop Spacer |
|-------|-----------------|

|       |              |
|-------|--------------|
| ZDVRS | Roof Support |
|-------|--------------|

|       |               |
|-------|---------------|
| ZDVSS | Siding Shield |
|-------|---------------|

|       |                                   |
|-------|-----------------------------------|
| ZDVWT | Wall Thimble (Horizontal Venting) |
|-------|-----------------------------------|

|         |  |
|---------|--|
| ZDV4FP8 | Flex Pipe 4" Diameter (4' Unexpanded to 8' Expanded) |
|---------|--|

|          |  |
|----------|--|
| ZDV4FP20 | Flex Pipe 4" Diameter (10' Unexpanded to 20' Expanded) |
|----------|--|

|        |                            |
|--------|----------------------------|
| ZDV4FC | Flex Connector 4" Diameter |
|--------|----------------------------|

|        |                           |
|--------|---------------------------|
| ZDV4SS | Spring 4" Standoff Spacer |
|--------|---------------------------|

|        |  |
|--------|--|
| ZDVAAF | Flashing 7" c/w Storm Collar (1/12 to7/12) |
|--------|--|

|        |  |
|--------|--|
| ZDVAF2 | Flashing 7" c/w Storm Collar (8/12 to 12/12) |
|--------|--|

|        |                                   |
|--------|-----------------------------------|
| ZDVAF3 | Flashing 7" c/w Storm Collar Flat |
|--------|-----------------------------------|

|        |                     |
|--------|---------------------|
| ZDV7SC | Storm Collar 7 Inch |
|--------|---------------------|

|         |   |
|---------|---|
| Z47GP36 | Galvanized Pipe 4/7" x 36" (Vertical Installations) |
|---------|---|

|         |  |
|---------|--|
| Z47GP48 | Galvanized Pipe 4/7 x 48" (Vertical Installations) |
|---------|--|




## -Glass Safety- All Units

### IT IS THE RESPONSIBILITY OF THE HOME OWNER TO ENSURE THAT NO ONE TOUCHES A HOT APPLIANCE.

If the barrier becomes damaged, the barrier shall be replaced with the manufacturer's barrier for this appliance.

Any safety screen, guard, or barrier removed for servicing the appliance, must be replaced prior to operating the appliance.

- Children and adults should be alerted to the hazards of the high surface temperatures of this appliance and should stay away to avoid burns or ignition of clothing.
- Do not clean when the glass is hot.
- Young children should be carefully supervised when they are in the same room as the appliance. Toddlers, young children and others may be susceptible to accidental contact burns.
- A physical barrier is recommended if there are at risk individuals in the house. To restrict access to a fireplace or stove, install an adjustable safety gate to keep toddlers, young children and other at risk individuals out of the room and away from hot surfaces.
- Do not leave the fireplace remote control where it is accessible to children.



# DANGER



**HOT GLASS WILL CAUSE BURNS.**

**DO NOT TOUCH GLASS UNTIL COOLED.**

**NEVER ALLOW CHILDREN TO TOUCH GLASS.**

A barrier designed to reduce the risk of burns from the hot viewing glass is provided with this appliance and must be installed for the protection of children and other at-risk individuals.

If the barrier becomes damaged, the barrier must be replaced with the manufacturer's barrier for this appliance.

## -Termination Cap Safety- All Units



# WARNING:

**A HORIZONTAL VENT CERTIFIED GUARD (SAFETY CAGE) IS AVAILABLE WHEN REQUIRED BY LOCAL CODES.**

### SAFETY CAGES ARE AVAILABLE FOR ALL HORIZONTAL VENT TERMINATIONS. CHECK WITH YOUR DEALER.

- **TERMINATION CAP IS HOT!** Do not place flammable materials on or within 24 inches of termination caps.
- It is imperative that the vent termination be located observing the minimum clearances as shown in manual.
- There must not be any obstruction such as bushes, garden sheds, fences, decks or utility buildings within 24" from the front of the termination plate.
- Do not locate termination where excessive snow or ice build-up may occur. Be sure to check vent termination area after snow falls and clear to prevent accidental blockage of venting system. When using snow blowers, make sure snow is not directed towards vent termination area.
- Venting terminal shall not be recessed into a wall or siding.



## LIMITED LIFETIME WARRANTY

This Limited Lifetime Warranty applies only while the unit remains at the site of the original installation and only if the unit is installed inside the continental United States, Alaska, Hawaii, and Canada. The warranty applies only if the unit is installed and operated in accordance with the printed instructions and in compliance with applicable installation and building codes and good trade practices.

### BASIC ONE YEAR WARRANTY

During the first year after installation of the appliance, we will provide a replacement for any component part of your unit found to be defective in materials or workmanship, including labour costs. Repair work requires prior approval by Kingsman, labour costs are based on a predetermined rate schedule and any repair work must be done through an authorized Kingsman dealer.

(Excluded Components: Accent Light Bulbs, Gasketing, Glass Fronts, and Paint)

### LIMITED LIFETIME WARRANTY

The heat exchanger, combustion chamber and burner of every Kingsman product excluding the Outdoor Firepit are warranted against materials or workmanship during the period the product is owned by the original owner. The part to be replaced must be returned to our distributor in exchange for the replacement part. Any labor, material, freight and/or handling charges associated with any repair or replacement pursuant to this Limited Lifetime Warranty will not be covered by this warranty.

### GENERAL TERMS

In lieu of providing a replacement part, we may, at our option, provide the distributor's component purchase price from us or a credit equal to the distributor's component purchase price from us toward the purchase of any new unit which we distribute. If a credit is given in lieu of a replacement part, the rating plate from the unit being replaced must be submitted on a warranty claim, and the unit being replaced must be made available to our distributor for disposition.

In establishing the date of installation for any purpose, including determination of the starting date for the term of this Limited Lifetime Warranty, reasonable proof of the original installation date must be presented\*, otherwise the effective date will be based upon the date of manufacture plus thirty (30) days.

We will not be responsible for and you, the user, will pay for: (a) damages caused by accident, abuse, negligence, misuse, riot, fire, flood, or Acts of God (b) damages caused by operating the unit where there is a corrosive atmosphere containing chlorine, fluorine, or any other damaging chemicals (other than in a normal residential environment) (c) damages caused by any unauthorized alteration or repair of the unit affecting its stability or performance (d) damages caused by improper matching or application of the unit or the unit's components (e) damages caused by failing to provide proper maintenance and service to the unit (f) any expenses incurred for erecting, disconnecting or dismantling the unit (g) parts or supplies used in connection with service or maintenance (h) damage repairs, inoperation or inefficiency resulting from faulty installation or application (i) electricity or fuel costs or any increase in electricity or fuel cost whatsoever including additional or unusual use of supplemental electric heat.

We shall not be liable for any incidental, consequential, or special damages or expenses in connection with any use or failure of this unit. We have not made and do not make any representation or warranty of fitness for a particular use or purpose, and there is no implied condition of fitness for a particular use or purpose. We make no express warranties except as stated in this Limited Lifetime Warranty. No one is authorized to change this Limited Lifetime Warranty or to create for us any other obligation or liability in connections with this unit. Any implied warranties shall last for one year after the original installation. Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages or do not allow limitations on how long an implied warranty or condition lasts, so the above limitations or exclusions may not apply to you. The provisions of this limited warranty are in additions to and not a modification of or subtraction from any statutory warranties and other rights and remedies provided by law.

Save this certificate. It gives you specific legal rights, and you may also have other rights which may vary from state to state and province to province.

In the event your unit needs servicing, contact your dealer or contractor who installed or serviced your unit. When requesting service, please have the model and serial number from each unit readily available. If your dealer needs assistance, the distributor is available for support and we, in turn support the distributor's efforts.

Fill in the installation date and model and serial numbers of the unit in the space provided below and retain this limited warranty for your files.

Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_ Date installed \_\_\_\_\_

Dealer or Contractor Name: \_\_\_\_\_

\*To receive advantage of your warranty, you must retain the original records that can establish the installation date of your unit.

**The Ultimate in Design, Engineering & Quality**